


# 1978 KM100-A3

**Kawasaki**  
Let the Good Times Roll®

## PARTS DIAGRAM

### GEAR CHANGE DRUM & FORKS (KM100-A6/A7)



# 1978 KM100-A3

## PARTS LIST

### GEAR CHANGE DRUM & FORKS (KM100-A6/A7)

| ITEM NAME                        | PART NUMBER | QUANTITY |
|----------------------------------|-------------|----------|
| PISTON 0.020' O.S (Ref # 1)      | 13029-014   |          |
| DRUM-ASSY-CHANGE (Ref # 2)       | 13239-5001  |          |
| DRUM ASSY,GEAR CHANGE (Ref # 2)  | 13239-1034  |          |
| HOLDER,GEAR CHANG DRM (Ref # 3)  | 13091-1059  |          |
| HOLDER (Ref # 3)                 | 13091-1077  |          |
| PLATE CHANGE DRUM PIN (Ref # 4)  | 13142-008   |          |
| HOLDER,CHANGE DRUM (Ref # 4)     | 13142-014   |          |
| SCREW PAN HEAD 6X30 (Ref # 5)    | 220B0630    |          |
| BOLT,SOCKET,6X30 (Ref # 5)       | 120P0630    |          |
| PIN,GEAR CHANGE DRUM (Ref # 6)   | 92042-042   |          |
| BEARING,BALL,#6905 (Ref # 7)     | 92045-036   |          |
| BEARING BALL #6004 (Ref # 7)     | 601B6004    |          |
| PIN-DOWEL,4X6 (Ref # 8)          | 610A0406    |          |
| ROTOR,NEUTRAL INDICTR (Ref # 9)  | 21007-1003  |          |
| WASHER PLAIN 6MM (Ref # 10)      | 410B0600    |          |
| SCREW PAN HEAD 6X16 (Ref # 11)   | 220B0616    |          |
| SHIFT FORK,LOW&2ND (Ref # 12)    | 13140-1026  |          |
| SHIFT FORK,3RD (Ref # 13)        | 13140-1027  |          |
| SHIFT FORK,4TH&TOP (Ref # 14)    | 13140-1028  |          |
| GASKET NEUTRAL SWITCH (Ref # 15) | 13146-002   |          |
| SWITCH,NEUTRAL (Ref # 16)        | 13151-1002  |          |
| SCREW PAN HEAD 6X16 (Ref # 17)   | 220B0616    |          |