


1977 KM100-A2

PARTS DIAGRAM

TURN SIGNALS (KM100-A1~A4)

Kawasaki
Let the Good Times Roll®



1977 KM100-A2

PARTS LIST

TURN SIGNALS (KM100-A1~A4)

ITEM NAME	PART NUMBER	QUANTITY
LAMP ASSY,TURN SIGNAL (Ref # 1)	23040-038	
SCREW-PAN HEAD,4X20 (Ref # 2)	220E0420A	
LENS,TURN SIGNAL LAMP (Ref # 3)	23048-1001	
LENS,TURN SIGNAL LAMP (Ref # 3)	23048-1001	
GASKET-SIG LAMP LENS (Ref # 4)	23050-003	
BULB,6V 21CP (Ref # 5)	92069-056	
BOLT-UPSET (Ref # 6)	112G0630	
WASHER PLAIN 6MM (Ref # 7)	411B0600	
WASHER SPRING 6MM (Ref # 8)	461F0600	
BRACKET,TURN SIGNAL (Ref # 9)	23051-047	
WASHER PLAIN 12MM (Ref # 10)	411B1200	
WASHER SPRING 12MM (Ref # 11)	461F1200	
NUT-HEX-FINE,12MM (Ref # 12)	315B1200	
NUT-HEX-FINE,12MM (Ref # 13)	315B1200	
NUT 6MM (Ref # 14)	311B0600	
WASHER,PLAIN,12M/M (Ref # 15)	411D1200	
WASHER-PLAIN,4MM (Ref # 16)	23058-002	