


1974 KS125

PARTS DIAGRAM

KICKSTARTER MECHANISM ('74-'75)

Kawasaki
Let the Good Times Roll®



1974 KS125

PARTS LIST

KICKSTARTER MECHANISM ('74-'75)

ITEM NAME	PART NUMBER	QUANTITY
PEDAL,KICKSTARTER (Ref # 1)	13064-019	1
RUBBER KICK PEDAL (Ref # 2)	13063-002	1
BOLT-SMALL-UPSET 8X25 (Ref # 3)	115G0825	1
PIN (Ref # 4)	92043-102	1
WASHER,PLAIN (Ref # 5)	92022-268	1
CIRCLIP 16MM (Ref # 6)	480J1600	4
GUIDE,KICKSPRING (Ref # 7)	13070-008	1
SPRING,KICKSTARTER (Ref # 8)	92082-005	1
SHAFT,KICKSTARTER (Ref # 9)	13066-1012	1
WASHER,PLAIN (Ref # 10)	92022-315	2
KICK GEAR&RATCHET ASY (Ref # 11)	13250-001	1
GEAR,KICKSTARTER (Ref # 11)	13068-032	1
KICK GEAR&RATCHET ASY (Ref # 12)	13250-001	1
RATCHET,KL250-D2 (Ref # 12)	13078-1052	1
SPRING,RATCHET (Ref # 13)	92081-122	1
WASHER-THRUST (Ref # 14)	92022-197	1
WASHER,PLAIN (Ref # 14)	92022-315	1
WASHER,PLAIN (Ref # 15)	92022-269	1
STOPPER,KICKSTARTER (Ref # 16)	32085-1061	1
GUIDE,KICKSTARTER (Ref # 17)	13206-010	1
WASHER,LOCK (Ref # 18)	92024-054	1
BOLT-UPSET (Ref # 19)	112G0618	2