


1974 KS125

PARTS DIAGRAM HANDLEBAR ('74-'75)

Kawasaki
Let the Good Times Roll®



1974 KS125

PARTS LIST

HANDLEBAR ('74-'75)

Kawasaki

Let the Good Times Roll®

ITEM NAME	PART NUMBER	QUANTITY
HANDLEBAR (Ref # 1)	46004-027	1
BOOTS,LEVER HOLDER (Ref # 2)	49006-1017	1
SCREW CABLE ADJUST (Ref # 3)	46055-003	2
NUT-LOCK (Ref # 4)	46056-005	2
BOLT HEX HEAD 5X20 (Ref # 5)	92007-020	2
BOLT,HEX HEAD,5X22 (Ref # 5)	92007-046	2
COLLAR LEVER (Ref # 6)	46059-011	2
HOLDER-CLUTCH LEV,BLK (Ref # 7)	46094-011-21	1
WASHER PLAIN 6MM (Ref # 8)	410B0600	2
BOLT-UPSET (Ref # 9)	112G0625	2
WASHER LOCK 5MM (Ref # 10)	464H0500	2
NUT 5MM (Ref # 11)	312B0500	2
NUT-LOCK,5MM (Ref # 11)	92019-014	2
LEVER-CLUTCH (Ref # 12)	46092-015	1
CASE ASSY,L.H.BLACK (Ref # 13)	46091-023-21	1
L.H GRIP SWITCH KIT (Ref # 14,15,)	99990-531	1
SCREW CNTSNK HD 3X8 (Ref # 14)	221B0308A	1
KNOB-L.H SWITCH (Ref # 15)	46044-011	1
SCREW PAN HEAD 3X5 (Ref # 16)	220B0305A	1
WASHER (Ref # 17)	92095-010	1
KNOB-SWITCH (Ref # 18)	46044-010	1
SCREW-PAN-CROS,5X25 (Ref # 19)	220B0525	1
SWITCH ASSY,HORN BUTN (Ref # 20)	27010-1009	1
SWITCH ASSY,HORN BUTN (Ref # 21)	27010-1009	1
SWITCH ASSY,HORN BUTN (Ref # 22)	27010-1009	1
WASHER LOCK (Ref # 23)	92095-012	1
LEVER,STARTER,BLACK (Ref # 24)	46096-008-10	1
WASHER PLAIN 6MM (Ref # 25)	410B0600	1
BOLT,6X10 (Ref # 26)	112G0610	1

1974 KS125

PARTS LIST

HANDLEBAR ('74-'75)

ITEM NAME	PART NUMBER	QUANTITY
REAR VIEW MIRROR,L.H (Ref # 27)	56003-009	1
REAR VIEW MIRROR,R.H (Ref # 28)	56002-020	1
BOOTS,LEVER HOLDER (Ref # 29)	49006-1017	1
SWITCH-FR. BRAKE LAMP (Ref # 30)	27021-004	1
HOLDER-FR BRK LEV,BLK (Ref # 31)	46060-009-21	1
LEVER FRONT BRAKE (Ref # 32)	46058-004	1
CAP-RR VIEW MIRROR (Ref # 33)	92102-009	1
GRIP ASSY,THROTTLE (Ref # 34)	46019-034	1
CASE ASSY,R.H (Ref # 35)	46018-036	1
HOLDER,CONTROL CABLE (Ref # 36)	46037-023	1
RUBBER-L.H GRIP (Ref # 37)	46075-019	1
SWITCH ASSY,L.H (Ref # 38)	46089-015	1