



# 1975 F7-D

## PARTS DIAGRAM

### ENGINE COVERS ('74-'75 F7-C/F6-D)



# 1975 F7-D

## PARTS LIST

### ENGINE COVERS ('74-'75 F7-C/F6-D)

ITEM NAME	PART NUMBER	QUANTITY
SCREW-PAN HEAD,6X90 (Ref # 1)	220B0690	
SCREW PAN HEAD 6X50 (Ref # 2)	220B0650	
COVER,BRK POINT,BUFF (Ref # 3)	14027-017-80	
GASKET-BREAKER COVER (Ref # 4)	14050-003	
COVER,L.H ENG,BUFF (Ref # 5)	14031-042-80	
GASKET-L.H ENGINE COV (Ref # 6)	14045-009	
CAP-RUBBER (Ref # 7)	92073-015	
SCREW PAN HEAD 6X55 (Ref # 8)	220B0655	
SEAL-OIL (Ref # 9)	92049-1249	
COVER,CHAIN.BUFF (Ref # 10)	14026-002-80	
GASKET-CHAIN CASE COV (Ref # 11)	14045-010	
TENSIONER-CHAIN (Ref # 12)	13123-006	
GASKET-R.H ENGINE COV (Ref # 13)	14046-018	
PLUG-FUEL DRAIN (Ref # 14)	92067-007	
GASKET-DRAIN PLUG (Ref # 15)	92065-073	
OIL SEAL TB16267 (Ref # 16)	92051-003	
COVER,R.H ENG.BUFF (Ref # 17)	14032-092-80	
HOLDER,CARBURETOR (Ref # 18)	16065-026	
SCREW PAN HEAD 6X12 (Ref # 19)	220B0612	
PLUG-OIL FILLER (Ref # 20)	16115-015	
"O" RING,20MM (Ref # 21)	670B2020	
COVER,OIL PUMP,BUFF (Ref # 22)	14030-029-80	
SCREW PAN HEAD 6X80 (Ref # 23)	220B0680	
SCREW PAN HEAD 6X20 (Ref # 24)	220B0620	
SCREW PAN HEAD 6X35 (Ref # 25)	220B0635	
SCREW PAN HEAD 6X40 (Ref # 26)	220B0640	
SCREW PAN HEAD 6X16 (Ref # 27)	220B0616	
HOLDER-CARBURETOR CAP (Ref # 28)	14065-002	
CAP,CARBURETOR (Ref # 29)	14038-037	

# 1975 F7-D

## PARTS LIST

### ENGINE COVERS ('74-'75 F7-C/F6-D)

ITEM NAME	PART NUMBER	QUANTITY
GASKET-CARBURETOR COV (Ref # 30)	14048-003	
COVER,CARB,BUFF (Ref # 31)	14030-057-80	
"0" RING,20MM (Ref # 32)	670B2020	
PLUG,CARBURETOR COVER (Ref # 33)	92067-022	
GROMMET-OVERFLOW PIPE (Ref # 34)	16136-005	