


# 1974 F7-C

## PARTS DIAGRAM

### CHASSIS ELECTRICAL EQUIPMENT

**Kawasaki**  
Let the Good Times Roll®



# 1974 F7-C

## PARTS LIST

### CHASSIS ELECTRICAL EQUIPMENT

| ITEM NAME                      | PART NUMBER | QUANTITY |
|--------------------------------|-------------|----------|
| WIRING HARNESS-MAIN (Ref # 1)  | 26001-076   |          |
| WIRING HARNESS-REAR (Ref # 2)  | 26002-029   |          |
| LEAD WIRE (Ref # 3)            | 26011-042   |          |
| FUSE ASSY (Ref # 4)            | 26004-017   |          |
| FUSE 10A (Ref # 5)             | 26006-003   |          |
| RELAY-TURN SIGNAL (Ref # 6)    | 27002-013   |          |
| HORN (Ref # 7)                 | 27003-061   |          |
| SPRING BRAKE LAMP SW (Ref # 8) | 27011-004   |          |
| SWITCH-BRAKE LAMP (Ref # 9)    | 27010-018   |          |
| YUA BAT 6N4-2A-5 (Ref # 10)    | K26012-020  |          |
| HOLDER,SPARE FUSE (Ref # 11)   | 26016-003   |          |
| FUSE 10A (Ref # 12)            | 26006-003   |          |