


1978 KZ200-A1

PARTS DIAGRAM

CHASSIS ELECTRICAL EQUIPMENT

Kawasaki
Let the Good Times Roll®



1978 KZ200-A1

PARTS LIST

CHASSIS ELECTRICAL EQUIPMENT

ITEM NAME	PART NUMBER	QUANTITY
FUSE ASSY (Ref # 1)	26004-035	1
DAMPER RUBBER,FUSE (Ref # 2)	92075-279	1
FUSE-20A (Ref # 3)	26006-005	2
FUSE 10A (Ref # 4)	26006-003	3
WIRE,MAGNETIC SWITCH (Ref # 5)	26010-051	1
BAND,WIRING HARNESS (Ref # 6)	92072-056	2
BAND,SHORT (Ref # 7)	92072-030	6
WIRING HARNESS,MAIN (Ref # 8)	26001-1158	1
RELAY-TURN SIGNAL (Ref # 9)	27002-011	1
BOLT-UPSET,6X12 (Ref # 10)	112G0612	2
WASHER SPRING 6MM (Ref # 11)	461F0600	2
HORN ASSY (Ref # 12)	27003-078	1
WIRE,BATTERY GROUND (Ref # 13)	26010-052	1
BOLT-UPSET,6X12 (Ref # 14)	112G0612	1
WASHER SPRING 6MM (Ref # 15)	461F0600	1
YUA BAT 12N10-3B (Ref # 16)	26012-050	1
SWITCH,BRAKE LIGHT (Ref # 17)	27010-025	1
NUT,BRAKE LAMP SWITCH (Ref # 18)	27037-001	1
SPRING,BRAKE LAMP SN (Ref # 19)	27011-017	1
LABEL-WARNING,BATTERY (Ref # 20)	56040-1036	1