


1974 F11-A

PARTS DIAGRAM

CHASSIS ELECTRICAL EQUIPMENT

Kawasaki

Let the Good Times Roll®



1974 F11-A

PARTS LIST

CHASSIS ELECTRICAL EQUIPMENT

ITEM NAME	PART NUMBER	QUANTITY
WIRING HARNESS-MAIN (Ref # 1)	26001-082	
FUSE ASSY (Ref # 2,3)	26004-014	
FUSE 15A (Ref # 3)	26006-007	
WIRE-LEAD (Ref # 4)	26011-065	
COVER-WIRING HARNESS (Ref # 5)	26009-005	
RELAY-TURN SIGNAL (Ref # 6)	27002-013	
HORN (Ref # 7)	27003-056	
HORN (Ref # 7)	27003-056	
BOLT HEX HEAD 8X16 (Ref # 8)	116B0816	
WASHER SPRING 8MM (Ref # 9)	461F0800	
WASHER PLAIN 8MM (Ref # 10)	411B0800	
YUA BAT 6N4B-2A-3 (Ref # 11)	26012-035	
SWITCH-BRAKE LAMP (Ref # 12)	27010-017	
SPRING-BRAKE LAMP SW (Ref # 13)	27011-012	
BAND,SHORT (Ref # 14)	92072-030	
BAND,MIDDLE (Ref # 15)	92072-031	
BAND,LONG (Ref # 16)	92072-032	
BAND-RUBBER (Ref # 17)	92072-035	