


1974 F11-A

PARTS DIAGRAM

IGNITION

Kawasaki
Let the Good Times Roll®



1974 F11-A

PARTS LIST

IGNITION

ITEM NAME	PART NUMBER	QUANTITY
COIL-IGNITION (Ref # 1)	21121-042	
CAP,SPARK PLUG (Ref # 2)	21130-021	
WIRE IGNITION LEAD (Ref # 3)	26011-014	
NUT,6MM (Ref # 4)	92019-019	
WASHER SPRING 6MM (Ref # 5)	461F0600	
MAGNETO ASSY (Ref # 6)	21002-024	
.BASE-MAGNETO (Ref # 7)	21048-012	
.ROTOR (Ref # 8)	21007-019	
.COIL-PRIMARY (Ref # 9)	21049-014	
.SCREW-PAN-CROS (Ref # 10)	220B0535	
.WASHER SPRING 5MM (Ref # 11)	461F0500	
.SCREW PAN HEAD 5X55 (Ref # 12)	220B0555A	
.BREAKER-CONTACT (Ref # 13)	21008-019	
.CONDENSER (Ref # 14)	21013-024	
.FELT OIL (Ref # 15)	21019-005	
FELT OIL (Ref # 15)	21019-005	
.SCREW PAN HEAD 4X8 (Ref # 16)	21085-004	
SCREW PAN HEAD 4X8 (Ref # 16)	220B0408	
.WASHER SPRING 4MM (Ref # 17)	461F0400	
.WASHER PLAIN 4MM (Ref # 18)	410B0400	
.GROMMET WIRING HARN (Ref # 19)	21017-005	
GROMMET (Ref # 20)	92071-048	
SCREW PAN HEAD 5X20 (Ref # 21)	220B0520	
WASHER PLAIN 5MM (Ref # 22)	410B0500	
NUT, 14MM (Ref # 23)	92015-048	
WASHER-PLAIN,18MM (Ref # 24)	92022-184	
WASHER LOCK 18MM (Ref # 25)	463G1800	
BAND RUBBER (Ref # 26)	92072-013	
SPARK PLUG B9EV (Ref # 27)	B9EV	