



1976 KX250-A3

PARTS DIAGRAM

IGNITION (74-76)

Kawasaki

Let the Good Times Roll®



1976 KX250-A3

PARTS LIST

IGNITION (74-76)

ITEM NAME	PART NUMBER	QUANTITY
BOLT (Ref # 1)	92001-1578	
WASHER SPRING 8MM (Ref # 2)	461F0800	
SCREW PAN HEAD 6X25 (Ref # 3)	220B0625	
WASHER SPRING 6MM (Ref # 4)	461F0600	
WASHER PLAIN 6MM (Ref # 5)	410B0600	
WASHER,PLAIN,8MM (Ref # 6)	92022-276	
STATOR ASSY (Ref # 7)	21003-020	
ROTOR,MAGNETO (Ref # 8)	21007-026	
WIRING HARNESS,MAGNET (Ref # 9)	21029-027	
CAP,SPARK PLUG (Ref # 10)	21130-1006	
TERMINAL,PLUG CAP (Ref # 11)	21169-001	
CLAMP,SPARK PLUG CAP (Ref # 12)	92037-1173	
SCREW-PAN-CROS (Ref # 13)	220B0310	
COIL,IGNITION (Ref # 14)	21121-070	
NUT,6MM (Ref # 15)	92019-019	
IGNITION UNIT (Ref # 16)	21119-018	
BOLT-UPSET (Ref # 17)	112G0618	
BOLT-UPSET (Ref # 17)	112G0618	
WASHER PLAIN (Ref # 18)	92022-024	