


1974 KX250

PARTS DIAGRAM HANDLEBAR (74-76)

Kawasaki
Let the Good Times Roll®



1974 KX250

PARTS LIST

HANDLEBAR (74-76)

ITEM NAME	PART NUMBER	QUANTITY
HANDLEBAR (Ref # 1)	46004-028	1
HANDLEBAR (Ref # 1)	46004-032	1
GRIP ASSY,THROTTLE (Ref # 2)	46019-031	1
GRIP,THROTTLE (Ref # 2-1)	46019-037	1
CASE,R.H,GRIP,UPPER (Ref # 3)	32099-1014	1
HOUSING-ASSY-CONTROL (Ref # 4)	46091-5006	1
SCREW PAN HEAD 5X18 (Ref # 5)	220B0518	2
LEVER ASSY,FRNT BRAKE (Ref # 6)	46021-024	1
LEVER ASSY,FRNT BRAKE (Ref # 6)	46021-032	1
LEVER,FRONT BRAKE (Ref # 7)	46058-017	1
FRONT BRAKE LEVER (Ref # 7)	46058-018	1
PIN COTTER 1.6X15 (Ref # 8)	550D1615	2
BOLT,HEX HEAD,6MM (Ref # 9)	92001-140	2
NUT CASTLE (Ref # 10)	320B0600	2
WASHER SPRING 6MM (Ref # 11)	461F0600	2
BOLT, HEX HEAD 6X22 (Ref # 12)	110N0622	2
WASHER PLAIN 6MM (Ref # 13)	411B0600	2
SCREW,CABLE ADJUST (Ref # 14)	46055-009	2
NUT,CABLE ADJUST LOCK (Ref # 15)	46056-006	2
BOOTS,LEVER HOLDER (Ref # 16)	49006-1017	2
RUBBER,L.H GRIP (Ref # 17)	46075-025	1
RUBBER,L.H GRIP (Ref # 17-1)	46075-027	1
LEVER ASSY,CLUTCH (Ref # 18)	46076-037	1
LEVER ASSY,CLUTCH (Ref # 18)	46076-048	1
LEVER,CLUTCH (Ref # 19)	46092-020	1
LEVER, CLUTCH (Ref # 19)	46092-021	1
BAND,SHORT (Ref # 20)	92072-030	2
BAND,MIDDLE (Ref # 21)	92072-031	2
BAND,WIRING HARNESS (Ref # 21)	92072-056	1

1974 KX250

PARTS LIST

HANDLEBAR (74-76)



ITEM NAME	PART NUMBER	QUANTITY
BAND-RUBBER (Ref # 22)	92072-035	2
BAND, LONG (Ref # 22)	92072-032	2
SWITCH, ASSY, ENG STOP (Ref # 23)	27010-1018	1
HOLDER, CLUTCH LEVER (Ref # 24)	46094-014	1
HOLDER, FR BRAKE LEVER (Ref # 25)	46060-010	1