


1978 KX250-A4

PARTS DIAGRAM

IGNITION (78-79)

Kawasaki
Let the Good Times Roll®



1978 KX250-A4

PARTS LIST

IGNITION (78-79)

ITEM NAME	PART NUMBER	QUANTITY
BOLT (Ref # 1)	92001-1578	1
WASHER SPRING 8MM (Ref # 2)	461F0800	1
WASHER,PLAIN,8MM (Ref # 3)	92022-276	1
SCREW PAN HEAD 6X25 (Ref # 4)	220B0625	2
WASHER SPRING 6MM (Ref # 5)	461F0600	2
WASHER PLAIN 6MM (Ref # 6)	410B0600	2
ROTOR,MAGNETO (Ref # 7)	21007-026	1
ROTOR,MAGNETO (Ref # 7)	21007-1013	1
STATOR ASSY (Ref # 8)	21003-1010	1
STATOR ASSY,MAGNETO (Ref # 8)	21003-1019	1
COIL,IGNITION (Ref # 9)	21121-1007	1
NUT (Ref # 10)	92019-008	2
CLAMP,SPARK PLUG CAP (Ref # 11)	92037-1173	1
SCREW-PAN-CROS (Ref # 12)	220B0310	1
TERMINAL,PLUG CAP (Ref # 13)	21169-001	1
CAP,SPARK PLUG (Ref # 14)	21130-1006	1
CAP,SPARK PLUG (Ref # 15)	21130-1001	1
IGNITION UNIT (Ref # 16)	21119-1001	1
IGNITION UNIT (Ref # 16)	21119-1010	1
BOLT-UPSET (Ref # 17)	112G0618	2
WASHER PLAIN (Ref # 18)	92022-024	2