





1980 KZ250

PARTS DIAGRAM

IGNITION SWITCH/LOCK ('80 D1)



1980 KZ250

PARTS LIST

IGNITION SWITCH/LOCK ('80 D1)



ITEM NAME	PART NUMBER	QUANTITY
KEY,BLANK (Ref # 1)	27008-1034	(1
KEY,BLANK (Ref # 2)	27008-1035	(1
BOLT-UPSET,6X16 (Ref # 3)	112G0616	2
WASHER SPRING 6MM (Ref # 4)	461F0600	2
SWITCH ASSY,IGNITION (Ref # 5)	27005-1031	1
SWITCH,BRAKE LIGHT (Ref # 6)	27010-025	1
NUT,BRAKE LAMP SWITCH (Ref # 7)	27037-001	1
SPRING,BRAKE LAMP SN (Ref # 8)	27011-017	1
LOCK ASSY (Ref # 9)	27004-5068	1