


1970 A1SS-A

PARTS DIAGRAM

CHASSIS ELECTRICAL EQUIPMENT

Kawasaki
Let the Good Times Roll®



1970 A1SS-A

PARTS LIST

CHASSIS ELECTRICAL EQUIPMENT

ITEM NAME	PART NUMBER	QUANTITY
WIRING HARNESS MAIN (Ref # 1)	26001-022	1
WIRING HARNESS MAIN (Ref # 2)	26001-036	1
WIRING HARNESS MAIN (Ref # 3)	26001-039	1
WIRING HARNESS REAR (Ref # 4)	26002-007	1
WIRE BATTERY GROUND (Ref # 5)	26010-014	1
WIRE BATTERY LEAD (Ref # 6)	26010-015	1
CAP BAT TERMINAL RUBB (Ref # 7)	92073-001	1
BAND RUBBER (Ref # 8)	92072-018	2
BAND RUBBER (Ref # 9)	92072-013	7
CAP IGNITION COIL (Ref # 10)	92073-003	2
FUSE ASSY (Ref # 11,12)	26004-026	1
FUSE ASSY (Ref # 11,12)	26004-005	1
FUSE 10A (Ref # 12)	26006-001	2
FUSE 20A (Ref # 12)	26006-002	2
HOUSING IGNITION SW (Ref # 13)	27009-001	1
SCREW PAN HEAD 6X12 (Ref # 14)	220B0612	2
WASHER SPRING 6MM (Ref # 15)	461F0600	2
SWITCH ASSY IGNITION (Ref # 16,17)	27005-013	1
KEY BLANK (Ref # 17)	27008-016	1
KEY BLANK (Ref # 17)	27008-016	1
KEY BLANK (Ref # 17)	27008-016	1
KEY BLANK (Ref # 17)	27008-016	1
KEY BLANK (Ref # 17)	27008-016	1
UNAVAILABLE IN PRICE BOOK (Ref # 17)	27008-027	1
UNAVAILABLE IN PRICE BOOK (Ref # 17)	27008-027	1
UNAVAILABLE IN PRICE BOOK (Ref # 17)	27008-027	1
UNAVAILABLE IN PRICE BOOK (Ref # 17)	27008-027	1
UNAVAILABLE IN PRICE BOOK (Ref # 17)	27008-027	1
KEY SET NO 521 (Ref # 17)	27008-027-21	1