


1973 Mach II

PARTS DIAGRAM

FOOTRESTS/STANDS/BRAKE PEDAL (S2)

Kawasaki
Let the Good Times Roll®



(S2)

1973 Mach II

PARTS LIST

FOOTRESTS/STANDS/BRAKE PEDAL (S2)

ITEM NAME	PART NUMBER	QUANTITY
SPRING,BRAKE PEDAL (Ref # 1)	43005-033	
SPRING,BRAKE PEDAL (Ref # 1)	43005-033	
PEDAL-BRAKE (Ref # 2)	43001-038	
PEDAL,BRAKE (Ref # 2)	43001-060	
WASHER BRAKE PEDAL (Ref # 3)	92022-085	
PIN COTTER 3.0X20 (Ref # 4)	550D3020	
WASHER PLAIN 6MM (Ref # 5)	410B0600	
PIN COTTER 2.0X15 (Ref # 6)	550D2015	
PIN R BRK CABLE JOINT (Ref # 7)	92043-034	
BOLT-UPSET (Ref # 8)	112G0618	
WASHER 6.5X20X1.6T (Ref # 9)	92022-125	
WASHER SPRING 6MM (Ref # 10)	461F0600	
RUBBER-FOOTREST (Ref # 11)	92076-019	
CIRCLIP 16MM (Ref # 12)	480J1600	
SPRING FOOTREST PEG (Ref # 13)	34006-002	
WASHER FOLDING PEG (Ref # 14)	92022-049	
BAR-FOOTREST (Ref # 15)	34003-028	
BOLT-L.H FOOTREST FIT (Ref # 16)	92003-076	
NUT-HEX-FINE,12MM (Ref # 17)	315B1200	
BOLT,R.H.FOOTREST FIT (Ref # 18)	92001-1068	
WASHER SPRING 12MM (Ref # 19)	461F1200	
RUBBER REAR FOOTREST (Ref # 20)	92076-008	
BAR SET-REAR FOOTREST (Ref # 21)	34030-001	
WASHER PLAIN 10MM (Ref # 22)	410B1000	
WASHER SPRING 10MM (Ref # 23)	461F1000	
NUT,10MM (Ref # 24)	314B1000	
STAND-SIDE (Ref # 25)	34024-051	
STAND-SIDE (Ref # 25)	34024-051	
SPRING MAIN STAND (Ref # 26)	34023-005	

1973 Mach II

PARTS LIST

FOOTRESTS/STANDS/BRAKE PEDAL (S2)

ITEM NAME	PART NUMBER	QUANTITY
DAMPER RUBB SIDE STND (Ref # 27)	92075-031	
UNAVAILABLE IN PRICE BOOK (Ref # 28)	11381035	
STAND-MAIN (Ref # 29)	34011-028	
SHAFT MAIN STAND (Ref # 30)	34019-011	
DAMPER RUBB-MAIN STND (Ref # 31)	92075-115	
COTTER PIN,3.0X25 (Ref # 32)	550D3025	
SPRING-MAIN STAND (Ref # 33)	34023-010	
COLLAR (Ref # 34)	92027-103	