


1973 Mach II

PARTS DIAGRAM

SEAT/SEAT COVER (S2)

Kawasaki

Let the Good Times Roll®



(S2)

1973 Mach II

PARTS LIST

SEAT/SEAT COVER (S2)

Kawasaki

Let the Good Times Roll®

ITEM NAME	PART NUMBER	QUANTITY
SEAT ASSY-DUAL (Ref # 1)	53001-070	
HOOK (Ref # 2)	53008-011	
HINGE,BLACK (Ref # 3)	53009-017-10	
HINGE-SEAT (Ref # 4)	53009-021	
PIN (Ref # 5)	53011-002	
COTTER PIN (Ref # 6)	92041-003	
DAMPER RUBB DUAL SEAT (Ref # 7)	92075-023	
WASHER PLAIN 6MM (Ref # 8)	411B0600	
WASHER SPRING 6MM (Ref # 9)	461F0600	
BOLT-UPSET 6X14 (Ref # 10)	112B0614	
HOOK ASSY (Ref # 11)	53045-001	
GRIP-SEAT (Ref # 12)	53042-004	
PLUG-SEAT GRIP (Ref # 13)	32112-004	
BACK RENT,P.C.RED (Ref # 14)	53043-001-84	
BACK RENT,P.C.RED (Ref # 14)	53043-001-84	
BOX-TOOL (Ref # 15)	32098-015	
BAND TOOL (Ref # 16)	92072-012	
BOLT SMALL (Ref # 17)	114G0812	
BOLT,8X20 (Ref # 18)	115G0820	
WASHER SPRING 8MM (Ref # 16)	461F0800	
WASHER PLAIN 8MM (Ref # 20)	411B0800	
BAND-SEAT STOPPER (Ref # 21)	92072-038	
BAND-SEAT STOPPER (Ref # 21)	92072-038	
REFLECTOR-REFLEX,REAR (Ref # 22)	28001-009	
NUT,5MM (Ref # 23)	311B0500	
WASHER SPRING 5MM (Ref # 24)	461F0500	
WASHER PLAIN 5MM (Ref # 25)	411B0500	
EMBLEM-L.H BACK REST (Ref # 26)	56027-050	
EMBLEM-R.H BACK REST (Ref # 27)	56027-052	