


1977 KZ400-A1

PARTS DIAGRAM

KICKSTARTER MECHANISM

Kawasaki
Let the Good Times Roll®



1977 KZ400-A1

PARTS LIST

KICKSTARTER MECHANISM

ITEM NAME	PART NUMBER	QUANTITY
BOLT-UPSET 6X14 (Ref # 1)	112B0614	2
WASHER-LOCK (Ref # 2)	92024-036	1
STOPPER,KICKSTARTER (Ref # 3)	13072-012	1
CIRCLIP,19MM (Ref # 4)	480J1900	1
CAP,KICKSTARTER (Ref # 5)	92102-008	1
SPRING RATCHET (Ref # 6)	92081-104	1
RATCHET,KICK SHAFT (Ref # 7)	13078-011	1
RATCHET,KICK SHAFT (Ref # 7)	13078-011	1
CIRCLIP,18MM (Ref # 8)	92033-029	1
WASHER THRUST (Ref # 9)	92022-112	1
GEAR,KICKSTARTER (Ref # 10)	13068-031	1
BUSHING,KICK SHAFT (Ref # 11)	92028-175	1
CIRCLIP, 20MM (Ref # 12)	480J2000	2
SPRING,KICK RETURN (Ref # 13)	92082-006	1
GUIDE,KICK SPRING (Ref # 14)	13070-009	1
SHAFT,KICKSTARTER (Ref # 15)	13066-036	1
SCREW CNTSNK HD 6X16 (Ref # 16)	221B0616	2
PLATE-DRUM LEV POSTON (Ref # 17)	13169-007	1
PEDAL ASY,KICKSTARTER (Ref # 18)	13058-053	1
CIRCLIP,KICK (Ref # 19)	92036-025	1
CIRCLIP,KICK (Ref # 19)	92036-026	1
WASHER,KICKPEDAL (Ref # 20)	92022-294	1
SPRING,KICK PEDAL (Ref # 21)	92081-136	1
PEDAL,KICKSTARTER (Ref # 22)	13060-017	1
RUBBER KICK PEDAL (Ref # 23)	13063-004	1
BOLT HEX HEAD 8X28 (Ref # 24)	114G0828	1
BOLT HEX HEAD 8X28 (Ref # 24)	114G0828	1