

PARTS DIAGRAM

KICKSTARTER MECHANISM

Let the Good Times Roll®



1978 KZ400-A2

PARTS LIST

KICKSTARTER MECHANISM

ITEM NAME	PART NUMBER	QUANTITY
BOLT-UPSET 6X14 (Ref # 1)	112B0614	
WASHER-LOCK (Ref # 2)	92024-036	
STOPPER,KICKSTARTER (Ref # 3)	13072-012	
CIRCLIP,19MM (Ref # 4)	480J1900	
CAP,KICKSTARTER (Ref # 5)	92102-008	
SPRING RATCHET (Ref # 6)	92081-104	
RATCHET,KICK SHAFT (Ref # 7)	13078-011	
RATCHET,KICK SHAFT (Ref # 7)	13078-011	
CIRCLIP,18MM (Ref # 8)	92033-029	
WASHER THRUST (Ref # 9)	92022-112	
GEAR,KICKSTARTER (Ref # 10)	13068-031	
BUSHING,KICK SHAFT (Ref # 11)	92028-175	
CIRCLIP, 20MM (Ref # 12)	480J2000	
SPRING,KICK RETURN (Ref # 13)	92082-006	
GUIDE,KICK SPRING (Ref # 14)	13070-009	
SHAFT,KICKSTARTER (Ref # 15)	13066-036	
SCREW CNTSNK HD 6X16 (Ref # 16)	221B0616	
PLATE-DRUM LEV POSTON (Ref # 17)	13169-007	
PEDAL ASY,KICKSTARTER (Ref # 18)	13058-053	
CIRCLIP,KICK (Ref # 19)	92036-025	
CIRCLIP,KICK (Ref # 19)	92036-026	
WASHER,KICKPEDAL (Ref # 20)	92022-294	
SPRING,KICK PEDAL (Ref # 21)	92081-136	
PEDAL,KICKSTARTER (Ref # 22)	13060-017	
RUBBER KICK PEDAL (Ref # 23)	13063-004	
BOLT HEX HEAD 8X28 (Ref # 24)	114G0828	
BOLT HEX HEAD 8X28 (Ref # 24)	114G0828	