


1977 KZ400-A1

PARTS DIAGRAM HANDLEBAR

Kawasaki
Let the Good Times Roll®



1977 KZ400-A1

PARTS LIST HANDLEBAR

ITEM NAME	PART NUMBER	QUANTITY
MIRROR-ASSY,LH&RH (Ref # 1)	56001-5008	2
SWITCH,L.H (Ref # 2)	46089-014	1
BOLT 8X38 (Ref # 3)	92001-1405	4
BOLT 8X38 (Ref # 3)	92001-1405	4
WASHER SPRING 8MM (Ref # 4)	461F0800	4
HOLDER-HANDLEBAR (Ref # 5)	46012-008	2
HANDLEBAR (Ref # 6)	46003-034	1
GRIP ASSY,THROTTLE (Ref # 7)	46019-038	1
RUBBER,R.H GRIP (Ref # 8)	46061-018	1
HOUSING ASSY,R.H (Ref # 9)	46091-1039	1
HOUSING ASSY,R.H (Ref # 9)	46091-1039	1
SCREW-PAN-CROS (Ref # 10)	220B0535	2
SCREW PAN HEAD 5X30 (Ref # 11)	220B0530	2
SWITCH ASSY,HORN BUTN (Ref # 12)	27010-1009	1
SWITCH ASSY,HORN BUTN (Ref # 13)	27010-1009	1
SWITCH ASSY,HORN BUTN (Ref # 13)	27010-1009	1
SWITCH ASSY,HORN BUTN (Ref # 14)	27010-1009	1
HOUSING ASSY,CONT,L.H (Ref # 15)	46091-1079	1
HOUSING ASSY,CONT,L.H (Ref # 15)	46091-1079	1
SCREW CNTSNK HD 3X8 (Ref # 16)	221B0308A	1
KNOB,LIGHTING SW L.H (Ref # 17)	46043-005	1
BUTTON, HORN PUSH (Ref # 18)	46028-006	1
SCREW PAN HEAD 3X5 (Ref # 19)	220B0305A	1
KNOB,LIGHTING SW L.H (Ref # 20)	46044-013	1
RUBBER,L.H GRIP (Ref # 21)	46075-028	1
LEVER ASSY,CLUTCH (Ref # 22)	46076-052	1
BOLT 6X22 (Ref # 23)	112B0622	1
WASHER PLAIN 6MM (Ref # 24)	411B0600	1
SCREW CABLE ADJUST (Ref # 25)	46055-003	1

1977 KZ400-A1

PARTS LIST

HANDLEBAR

Kawasaki

Let the Good Times Roll®

ITEM NAME	PART NUMBER	QUANTITY
SCREW,CABLE ADJUSTER (Ref # 25)	92009-1022	1
NUT,CABLE ADJUST NUT (Ref # 26)	46056-007	1
BOLT,HEX HEAD (Ref # 27)	92007-047	1
NUT (Ref # 28)	92019-008	1
NUT,LOCK 6MM (Ref # 28)	92017-014	1
HOLDER,CLUTCH LEVER (Ref # 29)	46094-017	1
LEVER,CLUTCH (Ref # 30)	46092-023	1
L.H GRIP SWITCH KIT (Ref # 31)	99990-530	AR