


1977 KZ400-A1

PARTS DIAGRAM

CHASSIS ELECTRICAL EQUIPMENT

Kawasaki

Let the Good Times Roll®



1977 KZ400-A1

PARTS LIST

CHASSIS ELECTRICAL EQUIPMENT

ITEM NAME	PART NUMBER	QUANTITY
WIRING HARNESS REAR (Ref # 1)	26002-049	1
WIRING HARNESS,MAIN (Ref # 2)	26001-136	1
FUSE ASSY (Ref # 3)	26004-035	1
FUSE-20A (Ref # 4)	26006-005	2
FUSE 10A (Ref # 5)	26006-003	3
DAMPER RUBBER,FUSE (Ref # 6)	92075-279	1
RELAY-TURN SIGNAL (Ref # 7)	27002-011	1
BOLT,8X20 (Ref # 8)	115G0820	1
WASHER SPRING 8MM (Ref # 9)	461F0800	1
HORN (Ref # 10)	27003-1006	1
HORN (Ref # 10)	27003-1006	1
SWITCH,BRAKE LIGHT (Ref # 11)	27010-025	1
NUT,BRAKE LAMP SWITCH (Ref # 12)	27037-001	1
SPRING,BRAKE LIGHT SW (Ref # 13)	27011-015	1
SWITCH,BK LIGHT IND (Ref # 14)	28019-002	1
BAND,LONG (Ref # 15)	92072-032	4
BAND,MIDDLE (Ref # 16)	92072-031	2
BAND,SHORT (Ref # 17)	92072-030	10
BAND,BREATHER WIRE (Ref # 18)	92072-067	2
YUA BAT 12N12A-4A-1 (Ref # 19)	26012-045	1
WIRE,LEAD (Ref # 20)	26010-044	1
LABEL-WARNING,BATTERY (Ref # 21)	56040-1036	1
CLAMP,WIRING HARNESS (Ref # 22)	21126-008	1
BAND-RUBBER (Ref # 23)	92072-035	2
WIRE,LEAD,REAR (Ref # 24)	26011-097	2