


1979 KZ400-B2

PARTS DIAGRAM

CHASSIS ELECTRICAL EQUIPMENT

Kawasaki
Let the Good Times Roll®



1979 KZ400-B2

PARTS LIST

CHASSIS ELECTRICAL EQUIPMENT

ITEM NAME	PART NUMBER	QUANTITY
FUSE ASSY (Ref # 1)	26004-035	
DAMPER RUBBER,FUSE (Ref # 2)	92075-279	
FUSE-20A (Ref # 3)	26006-005	
FUSE 10A (Ref # 4)	26006-003	
LEAD WIRE,SIGNAL LAMP (Ref # 5)	26011-063	
WIRE,LEAD,REAR SIGNAL (Ref # 6)	26011-1021	
HARNESS,MAIN (Ref # 7)	26001-1128	
RELAY-TURN SIGNAL (Ref # 8)	27002-011	
SWITCH,BK LIGHT IND (Ref # 9)	28019-002	
BAND,BREATHER WIRE (Ref # 10)	92072-067	
BAND,SHORT (Ref # 11)	92072-030	
BAND,MIDDLE (Ref # 12)	92072-031	
BAND,LONG (Ref # 13)	92072-032	
BOLT,8X20 (Ref # 14)	115G0820	
WASHER SPRING 8MM (Ref # 15)	461F0800	
WASHER PLAIN 8MM (Ref # 16)	410B0800	
CLAMP,CABLE (Ref # 17)	92037-155	
HORN (Ref # 18)	27003-1005	
SWITCH,BRAKE LIGHT (Ref # 19)	27010-025	
NUT,BRAKE LAMP SWITCH (Ref # 20)	27037-001	
SPRING,BRAKE LIGHT SW (Ref # 21)	27011-015	
WIRE LEAD,BATTERY GRD (Ref # 22)	26011-1022	
FB BAT FB12A-A (Ref # 23)	26012-1004	
LABEL-WARNING,BATTERY (Ref # 24)	56040-1036	