


1978 KZ400-C1

PARTS DIAGRAM

CHASSIS ELECTRICAL EQUIPMENT

Kawasaki
Let the Good Times Roll®



1978 KZ400-C1

PARTS LIST

CHASSIS ELECTRICAL EQUIPMENT

ITEM NAME	PART NUMBER	QUANTITY
FUSE ASSY (Ref # 1)	26004-035	1
DAMPER RUBBER,FUSE (Ref # 2)	92075-279	1
FUSE-20A (Ref # 3)	26006-005	2
FUSE 10A (Ref # 4)	26006-003	3
LEAD WIRE,SIGNAL LAMP (Ref # 5)	26011-063	3
WIRE,LEAD,REAR SIGNAL (Ref # 6)	26011-1021	1
HARNESS,MAIN (Ref # 7)	26001-1128	1
RELAY-TURN SIGNAL (Ref # 8)	27002-011	1
CAP BAT TERMINAL RUBB (Ref # 9)	92073-001	1
BAND,BREATHER WIRE (Ref # 10)	92072-067	2
BAND,SHORT (Ref # 11)	92072-030	4
BAND,MIDDLE (Ref # 12)	92072-031	4
BAND,LONG (Ref # 13)	92072-032	3
BOLT,8X20 (Ref # 14)	115G0820	1
WASHER SPRING 8MM (Ref # 15)	461F0800	1
WASHER PLAIN 8MM (Ref # 16)	410B0800	1
CLAMP,CABLE (Ref # 17)	92037-155	1
HORN (Ref # 18)	27003-1005	1
SWITCH,BRAKE LIGHT (Ref # 19)	27010-025	1
NUT,BRAKE LAMP SWITCH (Ref # 20)	27037-001	1
SPRING,BRAKE LIGHT SW (Ref # 21)	27011-015	1
WIRE,LEAD,BATTERY GRD (Ref # 22)	26011-1024	1
YUA BAT 12N5.5-4A (Ref # 23)	K26012-022	1
LABEL-WARNING,BATTERY (Ref # 24)	56040-1036	1
WIRE,LEAD,BATTERY (Ref # 25)	26011-1023	1