


1976 KX400-A2

PARTS DIAGRAM

FOOTRESTS/STAND/BRAKE PEDAL

Kawasaki
Let the Good Times Roll®



1976 KX400-A2

PARTS LIST

FOOTRESTS/STAND/BRAKE PEDAL

ITEM NAME	PART NUMBER	QUANTITY
BAR,FOOTREST,L.H (Ref # 1)	34028-025	
BAR,FOOTREST,R.H (Ref # 2)	34028-026	
SPRING,L.H,FOOTREST (Ref # 3)	92081-1254	
SPRING,R.H,FOOTREST (Ref # 4)	92081-1255	
PIN,FOOTREST BAR FIT (Ref # 5)	92043-115	
WASHER PLAIN 8MM (Ref # 6)	410B0800	
PIN,COTTER,2.5X15 (Ref # 7)	550D2515	
STAND-SIDE (Ref # 8)	34024-045	
SPRING,SIDE STAND (Ref # 9)	34025-008	
BRACKET, SIDE STRAND (Ref # 10)	34008-009	
BOLT-SMALL-UPSET,8X22 (Ref # 11)	115B0822	
WASHER SPRING 8MM (Ref # 12)	461F0800	
NUT 8MM (Ref # 13)	312B0800	
BOLT,10X28 (Ref # 14)	113G1028	
NUT 10MM (Ref # 15)	315B1000	
PEDAL,BRAKE (Ref # 16)	43077-005	
SPRING,BRAKE PEDAL (Ref # 17)	43005-035	
BOLT-UPSET 6X14 (Ref # 18)	112B0614	
WASHER SPRING 6MM (Ref # 19)	461F0600	
"O" RING,16MM (Ref # 20)	670B2016	
WASHER,PLAIN,6MM (Ref # 21)	92022-284	
DAMPER RUBBER BRK PED (Ref # 22)	92075-267	
SCREW PAN HEAD 5X10 (Ref # 23)	220B0510	
WASHER SPRING 5MM (Ref # 24)	461F0500	