

1974 Mach IV

PARTS DIAGRAM

REAR HUB/BRAKE/CHAIN

NO IMAGE AVAILABLE

1974 Mach IV

PARTS LIST

REAR HUB/BRAKE/CHAIN

ITEM NAME	PART NUMBER	QUANTITY
PANEL-ASY,RR BRK,BUFF (Ref # 1)	42006-026-80	
PANEL-ASY,RR BRK,BUFF (Ref # 1)	42006-036-80	
LEVER,REAR BRAKE CAM (Ref # 2)	42029-033	
LEVER,REAR BRAKE CAM (Ref # 2)	42029-033	
BOLT-SMALL-UPSET 8X25 (Ref # 3)	115G0825	
DUST SHIELD-BRAKE CAM (Ref # 4)	41051-003	
CAM SHAFT-BRAKE (Ref # 5)	41050-011	
CAM SHAFT,BRAKE (Ref # 5)	41050-017	
SHOE,BRAKE (Ref # 6)	41048-016	
SPRING,BRAKE SHOE (Ref # 7)	41049-012	
WASHER-BRAKE SHOE (Ref # 8)	41045-006	
PIN COTTER 3.0X25 (Ref # 9)	550D3025	
DRUM ASSY-REAR BRAKE (Ref # 10)	42005-026	
DRUM ASSY,REAR BRAKE (Ref # 10)	42005-030	
BEARING BALL #6304 (Ref # 11)	601B6304	
DAMPER-REAR HUB SHOCK (Ref # 12)	42014-018	
SPACER-RR HUB BEARING (Ref # 13)	42010-021	
BALL BEARING,#6304Z (Ref # 14)	601B6304Z	
COUPLING ASSY-RR HUB (Ref # 15)	42008-010	
SLEEVE-REAR AXLE (Ref # 16)	42036-012	
BOLT-REAR SPROCKET (Ref # 17)	92003-087	
BALL BEARING,#6206 (Ref # 18)	601B6206	
OIL SEAL (Ref # 19)	92050-027	
COLLAR,RR HUB COUPLNG (Ref # 20)	42037-023	
WASHER-LOCK (Ref # 21)	92088-013	
NUT 10MM (Ref # 22)	42045-005	
AXLE-REAR (Ref # 23)	42031-032	
AXLE,REAR (Ref # 23)	42031-045	
COLLAR-REAR AXLE (Ref # 24)	42032-030	

1974 Mach IV

PARTS LIST

REAR HUB/BRAKE/CHAIN

ITEM NAME	PART NUMBER	QUANTITY
NUT CASTLE,18MM (Ref # 25)	42045-018	
PIN-COTTER,4.0X35 (Ref # 26)	550D4035	
WASHER,PLAIN,20MM (Ref # 27)	92022-248	
WASHER,PLAIN,20MM (Ref # 27)	92022-249	
REAR SPROCKET,47T (Ref # 28)	42041-106	
RR SPROCKET 45T (OPT) (Ref # 28)	42041-108	
RR SPROCKET 49T (OPT) (Ref # 28)	42041-109	
DR CHAIN 530X110E (Ref # 29)	92057-017	
DR CHAIN 530X120E (Ref # 29)	92057-041	
INDICATOR,BRAKE SHOE (Ref # 30)	41085-004	