


1976 KZ750-B1

PARTS DIAGRAM

METERS/IGNITION SWITCH

Kawasaki

Let the Good Times Roll®



1976 KZ750-B1

PARTS LIST

METERS/IGNITION SWITCH

ITEM NAME	PART NUMBER	QUANTITY
SPEEDOMETER,MPH (Ref # 1)	25006-052	1
SPEEDOMETER,MPH (Ref # 1)	25005-1037	1
SPEEDO ASSY,KPH (Canada) (Ref # 1)	25006-054	1
SPEEDOMETER ASSY,KPH (Canada) (Ref # 1)	25005-1013	1
TACHOMETER ASSY (Ref # 2)	25015-1008	1
TACHOMETER ASSY (Ref # 2)	25015-1008	1
NUT,IGNITION SW LOCK (Ref # 3)	27007-004	1
COVER,METER,INDICATER (Ref # 4)	25023-015	1
HOLDER IGNITION SW (Ref # 5)	27019-003	1
SWITCH,IGNITION (Ref # 6)	27005-083	1
SWITCH-ASSY,IGNITION (Ref # 6)	27005-5006	1
KEY SET,#801 (Ref # 7)	27008-068-01	AR
KEY SET,#845 (Ref # 7)	27008-068-45	AR
KEY,BLANK (Ref # 7)	27008-1014	AR
KEY-LOCK,BLANK (Ref # 7)	27008-1103	AR
BRACKET,METER (Ref # 8)	25008-045	1
COLLAR,METER (Ref # 9)	92027-211	4
RUBBER,METER (Ref # 10)	92075-172	4
WASHER,PLAIN,5MM (Ref # 11)	92022-241	4
WASHER SPRING 5MM (Ref # 12)	461F0500	4
NUT 5MM (Ref # 13)	312B0500	4
SOCKET,SPEEDOMETER (Ref # 14)	25011-049	1
BULB 12V 3W (Ref # 15)	92069-018	10
DAMPER RUBBER (Ref # 16)	92075-080	4
WASHER PLAIN 8MM (Ref # 17)	411B0800	2
WASHER SPRING 8MM (Ref # 18)	461F0800	2
NUT,8MM (Ref # 19)	311B0800	2
COVER,TACHOMETER (Ref # 20)	25012-011	1
WASHER SPRING 3MM (Ref # 21)	461F0300	5

1976 KZ750-B1

PARTS LIST

METERS/IGNITION SWITCH

ITEM NAME	PART NUMBER	QUANTITY
SCREW PAN HEAD 3X8 (Ref # 22)	220B0308	5
COVER,METER BRACKET (Ref # 23)	25024-006	1
COVER,SPEEDOMETER (Ref # 24)	25012-010	1
LOCK SET,KZ750B4 (Ref # 25)	27004-5029	AR