


1978 Police 1000

PARTS DIAGRAM

HANDLEBAR ('78 C1/C1A)

Kawasaki

Let the Good Times Roll®



1978 Police 1000

PARTS LIST

HANDLEBAR ('78 C1/C1A)

Kawasaki

Let the Good Times Roll®

ITEM NAME	PART NUMBER	QUANTITY
LEVER ASSY,CLUTCH (Ref # 1)	46076-054	1
LEVER,CLUTCH (Ref # 2)	46092-023	1
BOLT,HEX HEAD (Ref # 3)	92007-047	1
NUT,CABLE ADJUST NUT (Ref # 4)	46056-007	1
SCREW CABLE ADJUST (Ref # 5)	46055-003	1
HOLDER,CLUTCH LEVER (Ref # 6)	46094-019	1
NUT (Ref # 7)	92019-008	1
WASHER PLAIN 6MM (Ref # 8)	410B0600	1
BOLT HEX HEAD 6X25 (Ref # 9)	110N0625	1
SWITCH,CLUTCH (Ref # 10)	27043-002	1
BOLT 8X38 (Ref # 11)	92001-1405	4
WASHER SPRING 8MM (Ref # 12)	461F0800	4
HOLDER,HANDLEBAR (Ref # 13)	46012-1001	1
HANDLE (Ref # 14)	46003-4008	1
RUBBER,L.H GRIP (Ref # 15)	46075-028	1
HOUSING-ASSY-CNTL,LH (Ref # 16)	46091-4002	1
SCREW CNTSNK HD 3X8 (Ref # 17)	221B0308A	1
KNOB,LIGHTING SW L.H (Ref # 18)	46044-013	1
SCREW PAN HEAD 3X5 (Ref # 19)	220B0305A	2
WASHER (Ref # 20)	92095-010	3
KNOB,LIGHTING SW L.H (Ref # 21)	46043-005	1
SCREW PAN HEAD 5X30 (Ref # 22)	220B0530	2
SCREW-PAN-CROS (Ref # 23)	220B0535	1
HOUSING ASSY,R.H (Ref # 24)	46091-1009	1
GRIP ASSY,THROTTLE (Ref # 25)	46019-038	1
KNOB,LIGHTING SW R.H (Ref # 26)	46043-004	1
SWITCH ASSY,HORN BUT (Ref # 27)	27010-1009	1
SWITCH ASSY,HORN BUT (Ref # 28)	27010-1009	1
SWITCH ASSY,HORN BUT (Ref # 29)	27010-1009	1