





1983 KDX80

PARTS DIAGRAM

IGNITION/GENERATOR (KDX80-B3)

Kawasaki
Let the Good Times Roll®

E1810-0072



1983 KDX80

PARTS LIST

IGNITION/GENERATOR (KDX80-B3)

ITEM NAME	PART NUMBER	QUANTITY
STATOR (Ref # 21003)	21003-1239	1
FLYWHEEL,MAGNETO (Ref # 21007)	21007-1018	1
IGNITER (Ref # 21119)	21119-1115	1
NUT,10MM (Ref # 92015)	92015-1415	1
BAND,WIRING HARNESS (Ref # 92072)	92072-056	1
BOLT-FLANGED,6X16 (Ref # 130)	130G0616	1
SCREW-PAN-CROS (Ref # 220)	220B0514	3
WASHER PLAIN 5MM (Ref # 410)	410B0500	3
WOODRUFF KEY (Ref # 510)	510A3200	1