

1982 CSR

PARTS DIAGRAM


STARTER MOTOR/STARTER CLUTCH

Kawasaki

Let the Good Times Roll®



E1840-0011



1982 CSR

PARTS LIST

STARTER MOTOR/STARTER CLUTCH

ITEM NAME	PART NUMBER	QUANTITY
COVER MAGNETIC SWITCH (Ref # 11012)	21141-004	1
CLUTCH ASSY,ONEWAY (Ref # 13193)	13193-1002	1
GEAR-COMP,ONEWAY (Ref # 13216)	16085-1032	1
GEAR-COMP,STARTER IDL (Ref # 13216A)	13216-1009	1
BRUSH,CARBON(+) (Ref # 21039)	21039-1001	1
BRUSH,CARBON(-) (Ref # 21039A)	21039-1002	1
SPRING,CARBON BRUSH (Ref # 21040)	21040-1001	2
STARTER-ELECTRIC (Ref # 21163)	21163-1199	1
WIRE,STARTER MOTOR (Ref # 26011)	26011-1049	1
WIRE-LEAD,MAGNETIC SW (Ref # 26011A)	26011-1128	1
SWITCH,MAGNETIC (Ref # 27010)	27010-1050	1
BOLT,PAN HEAD,5X108.5 (Ref # 92001)	92001-1156	2
BOLT SET,STARTER MOTO (Ref # 92001A)	92001-1204	1
BOLT (Ref # 92001B)	120P0816	3
SCREW,TAPPING,3.5X8 (Ref # 92009)	92009-1058	1
WASHER,THRUST,0.2T (Ref # 92022)	21025-011	2
WASHER,THRUST (Ref # 92022A)	92022-1129	3
WASHER,THRUST SUPPORT (Ref # 92022B)	92022-1130	1
WASHER,BAKELITE (Ref # 92022C)	92022-1131	1
WASHER,THRUST,0.8T (Ref # 92022D)	92022-1132	1
WASHER,LOCK (Ref # 92022E)	92022-1133	2
WASHER 22X35.5X1.0T (Ref # 92026)	92026-092	1
PIN (Ref # 92043)	92043-132	3
"O" RING,56MM (Ref # 92055)	92055-1042	2
GROMMET,CORD (Ref # 92071)	21017-017	1
CAP,MAGNETIC SWITCH (Ref # 92071A)	21017-023	1
DAMPER MAG SWITCH SHK (Ref # 92075)	21064-002	1
SPRING,COIL (Ref # 92081)	92081-159	3
ROLLER (Ref # 92122)	92122-006	3

1982 CSR

PARTS LIST

STARTER MOTOR/STARTER CLUTCH

ITEM NAME	PART NUMBER	QUANTITY
BOLT-UPSET,6X20 (Ref # 110)	112G0620	2
NUT 6MM (Ref # 311)	311B0600	1
NUT,6M/M (Ref # 311A)	311G0600	1
NUT 6MM (Ref # 312)	312B0600	1
WASHER PLAIN 6MM (Ref # 411)	411B0600	2
WASHER SPRING 5MM (Ref # 461)	461F0500	2
WASHER SPRING 6MM (Ref # 461A)	461F0600	2
PIN,DOWEL,3X6 (Ref # 551)	551A0306	1
"O" RING,5MM (Ref # 670)	670B1505	2
"O" RING,25MM (Ref # 671)	671B2525	1