


1978 Z1R

PARTS DIAGRAM

FRONT WHEEL/TIRE/HUB ('78 D1)



1978 Z1R

PARTS LIST

FRONT WHEEL/TIRE/HUB ('78 D1)

ITEM NAME	PART NUMBER	QUANTITY
COLLAR,FRONT AXLE (Ref # 1)	41069-033	2
AXLE,FRONT (Ref # 2)	41068-049	1
COLLAR,FRONT AXLE (Ref # 3)	41069-032	1
SOLID WHEEL ASSY,FRN (Ref # 4)	41073-1037	1
BOLT (Ref # 5)	92001-158	8
WASHER,LOCK (Ref # 6)	92088-023	4
DUST COVER (Ref # 7)	41042-014	1
BEARING BALL #6203 (Ref # 8)	601B6203	2
COLLAR,BRG (Ref # 9)	41039-028	1
RING, SNAP,43.5M/M (Ref # 10)	92033-1040	1
OIL SEAL (Ref # 11)	654A254008	1
DUST COVER (Ref # 12)	41042-015	1
GEAR BOX ASSY (Ref # 13)	41078-1004	1
PIN,SPRING (Ref # 14)	41082-001	1
WASHER THRST SPD PIN (Ref # 15)	41063-001	2
PINION,SPEEDOMETER (Ref # 16)	41060-017	1
BUSH,SPEEDMETER CABL (Ref # 17)	41062-005	1
GEAR,SPEEDOMETER (Ref # 18)	41060-1010	1
OIL SEAL,BJN30427-C3 (Ref # 19)	92049-1057	1
RECEIVER,GEAR (Ref # 20)	41064-013	1
BALANCER-WHEEL,10G (Ref # 21)	41075-1011	AR
BALANCER-WHEEL,20G (Ref # 22)	41075-1012	AR
BALANCER-WHEEL,30G (Ref # 23)	41075-1013	AR
TUBE 300/325/360-18 (Ref # 24)	41022-028	1
TIRE 350H-18 F6 (Ref # 25)	41002-1027	1