

1979 Shaft

PARTS DIAGRAM

TURN SIGNALS

NO IMAGE AVAILABLE

1979 Shaft

PARTS LIST

TURN SIGNALS

Kawasaki

Let the Good Times Roll®

ITEM NAME	PART NUMBER	QUANTITY
LAMP ASSY,TURN SIGNAL (Ref # 1)	23040-1017	2
SCREW-PAN-CROS (Ref # 2)	220E0412	8
WASHER-PLAIN,4MM (Ref # 3)	23058-002	8
LENS-SIGNAL LAMP (Ref # 4)	23048-1022	4
GASKET,TURN SIGNAL (Ref # 5)	11009-1052	4
BULB,12V 23/8W (Ref # 6)	92069-060	2
BRK,TURN SIGNAL LAMP (Ref # 7)	23051-1031	2
BOLT-UPSET (Ref # 8)	112G0630	4
WASHER PLAIN 6MM (Ref # 9)	411B0600	8
WASHER SPRING 6MM (Ref # 10)	461F0600	4
NUT 6MM (Ref # 11)	311B0600	4
DAMPER RUBBER (Ref # 12)	92075-128	4
NUT 10MM (Ref # 13)	315B1000	4
LAMP ASSY,TURN SIGNAL (Ref # 14)	23040-1018	2
BULB 12V 32CP (Ref # 15)	92069-055	2
DAMPER RUBBER,SIG LM (Ref # 16)	92075-158	4
COLLAR (Ref # 17)	92027-147	4
WASHER SPRING 10MM (Ref # 18)	461F1000	4
BRACKET,TURN SIGNAL (Ref # 19)	23051-1014	2