


1980 KZ1300-B2

PARTS DIAGRAM

STARTER MOTOR/STARTER CLUTCH

Kawasaki

Let the Good Times Roll®



1980 KZ1300-B2

PARTS LIST

STARTER MOTOR/STARTER CLUTCH

ITEM NAME	PART NUMBER	QUANTITY
BOLT,SOCKET,8X30 (Ref # 1)	120P0830	3
BOLT,FLANGED,6X25 (Ref # 2)	130B0625	1
BOLT,FLANGED,6X40 (Ref # 3)	130B0640	1
BOLT,FLANGED,6X55 (Ref # 4)	130G0655	2
PIN-PISTON (Ref # 5)	13002-019	1
CLUTCH-ASSY-ONEWAY (Ref # 6)	13193-1012	1
PIN (Ref # 7)	92043-087	3
SPRING (Ref # 8)	92081-110	3
ROLLER (Ref # 9)	92122-004	3
COVER,STARTER MOTOR (Ref # 10)	14025-1752	1
GEAR,STARTER CLUTCH (Ref # 11)	16085-1010	1
GEAR,STARTER REDUCTON (Ref # 12)	16085-1011	1
MOTOR ASSY,STARTER (Ref # 13)	21163-1005	1
"O" RING,STARTING MTR (Ref # 14)	21027-004	1
"O" RING,STARTING MTR (Ref # 15)	21027-003	2
SPRING,CARBON BRUSH (Ref # 16)	21040-003	2
CARBON BRUSH (Ref # 17)	21039-003	2
SCREW,PAN HEAD,6X110 (Ref # 18)	21015-005	2
GROMMET,CORD (Ref # 19)	21017-017	1
WIRE,LEAD,STARTER MTR (Ref # 20)	26011-1054	1
WASHER SPRING 6MM (Ref # 21)	461F0600	2
NUT 6MM (Ref # 22)	312B0600	2
WASHER,THRUST,0.2T (Ref # 23)	21025-011	AR
WASHER,THRUST,1.6T (Ref # 24)	21025-010	1
SWITCH,MAGNETIC (Ref # 25)	27010-1025	1
DAMPER MAG SWITCH SHK (Ref # 26)	21064-002	1
COVER,MAGNETIC SWITCH (Ref # 27)	14025-1165	1
NUT,LOCK 6MM (Ref # 28)	92017-014	2
DAMPER,TORSION (Ref # 29)	92075-1118	1

1980 KZ1300-B2

PARTS LIST

STARTER MOTOR/STARTER CLUTCH

ITEM NAME	PART NUMBER	QUANTITY
HUB,TORSION DAMPER (Ref # 30)	49030-1002	1
BOLT,DAMPER,L.H.THRED (Ref # 31)	92001-1212	1
WASHER,PLAIN (Ref # 32)	92022-1108	3
WASHER-PLN,11X36X4 (Ref # 33)	92022-307	1
SPACER,25X34X2.3 (Ref # 34)	92026-1059	2
PLATE,CLUTCH STARTER (Ref # 35)	92026-112	1
CLAMP,LEAD WIRE (Ref # 36)	92037-1345	2