

PARTS DIAGRAM

TURN SIGNALS

Let the Good Times Roll®



1981 KZ1300-A3

PARTS LIST

TURN SIGNALS

ITEM NAME	PART NUMBER	QUANTITY
LAMP ASSY,TURN SIGNAL (Ref # 1)	23040-1021	2
GASKET,TURN SIGNAL (Ref # 2)	11009-1102	4
SCREW,PAN HEAD,4X16 (Ref # 3)	220E0416A	8
LENS SIGNAL LAMP FR (Ref # 4)	23048-1020	4
WASHER-PLAIN,4MM (Ref # 5)	23058-002	8
BULB,12V 23/8W (Ref # 6)	92069-060	2
BRACKET,TURN SIGNAL (Ref # 7)	23051-1023	4
BOLT-UPSET (Ref # 8)	112G0630	4
NUT 6MM (Ref # 9)	311B0600	4
WASHER PLAIN 6MM (Ref # 10)	411B0600	8
WASHER SPRING 6MM (Ref # 11)	461F0600	4
LAMP,ASSY,TURN SIGNAL (Ref # 12)	23040-1022	2
BULB 12V 32CP (Ref # 13)	92069-055	2
WASHER SPRING 10MM (Ref # 15)	461F1000	4
COLLAR (Ref # 16)	92027-147	4
DAMPER RUBBER (Ref # 17)	92075-128	4
DAMPER RUBBER,SIG LM (Ref # 18)	92075-158	4