

1977 JS440

PARTS LIST

ELECTRIC CASE ('77-'78 A1/A1A/A2)

ITEM NAME	PART NUMBER	QUANTITY
SPARK PLUG B7ES (Ref # 1)	B7ES	2
SPARK PLUG BR7ES (Ref # 1)	BR7ES	2
CAP,PLUG (Ref # 2)	21130-504	2
CAP-SPARK PLUG (Ref # 2)	21130-508	2
SPRING,PLUG CAP (Ref # 3)	92081-542	2
COVER,PLUG (Ref # 4)	92071-501	2
GROMMET,SPARK PLUG (Ref # 4)	92071-535	2
GROMMET (Ref # 5)	92071-517	2
GROMMET (Ref # 5)	92071-517	2
UNAVAILABLE IN PRICE BOOK (Ref # 6)	110R06030	2
WASHER (Ref # 7)	411S0600	2
WASHER (Ref # 8)	92022-553	2
COLLAR (Ref # 9)	92027-519	2
CLAMP (Ref # 10)	92037-523	2
BRACKET,CLAMP (Ref # 11)	59016-514	1
BRACKET,CLAMP (Ref # 11)	11034-3005	1
NUT,6M/M (Ref # 12)	311R0600	2
NUT,6M/M (Ref # 12)	311R0600	3
WASHER (Ref # 13)	92022-553	2
BOLT 6X14 (Ref # 14)	110R0614	4
WASHER-SPRING,6MM (Ref # 15)	461S0600	4
PLATE-ELECTRICAL CASE (Ref # 16)	59086-516	1
GROMMET (Ref # 17)	92071-526	1
CASE,ELECTRIC (1) (Ref # 18)	59021-531	1
CASE,ELECTRIC (Ref # 18)	59416-3001	1
CASE,ELECTRIC (2) (Ref # 19)	59021-532	1
GASKET,CASE (Ref # 20)	11009-3024	1
BOLT,HEX HEAD,6X25 (Ref # 21)	110R0625	2
WASHER-SPRING,6MM (Ref # 22)	461S0600	2

1977 JS440

PARTS LIST

ELECTRIC CASE ('77-'78 A1/A1A/A2)

ITEM NAME	PART NUMBER	QUANTITY
WASHER (Ref # 23)	410S0600	2
WIRE,EARTH (Ref # 24)	26011-505	1
NUT,6M/M (Ref # 25)	311R0600	4
NUT,6M/M (Ref # 25)	311R0600	4
WASHER-SPRING,6MM (Ref # 26)	461S0600	4
WASHER (Ref # 27)	411S0600	4
STUD,6X98 (Ref # 28)	92004-3007	4
COIL,IGNITION (Ref # 29)	21121-518	1
COIL,IGNITION (Ref # 29)	21121-518	1
BRACKET,COIL (Ref # 30)	59016-521	1
WASHER SPRING 6MM (Ref # 31)	461F0600	2
NUT 6MM (Ref # 32)	311B0600	2
BOLT-UPSET-WS,6X14 (Ref # 33)	180B0614	2
IGNITER (Ref # 34)	21119-3004	1
IGNITER (Ref # 34)	21119-3004	1
WASHER,IGNITER (Ref # 35)	92022-3013	2
WASHER,IGNITER (Ref # 35)	92022-3013	2
BOLT-UPSET-WS,6X22 (Ref # 36)	180B0622	2
SWITCH,MAGNETIC (Ref # 37)	21164-515	1
BOLT SMALL (Ref # 38)	114G0812	2
WASHER SPRING 5MM (Ref # 39)	461F0500	2
REGULATOR (Ref # 40)	21066-501	1
BOLT-UPSET 6X14 (Ref # 41)	112B0614	2
WASHER SPRING 6MM (Ref # 42)	461F0600	2
WASHER PLAIN 6MM (Ref # 43)	410B0600	2
JOINT-STATOR WIRE (Ref # 44)	59071-516	3
"O" RING,16MM (Ref # 45)	670B2016	3
WIRE,LEAD (Ref # 46)	26011-516	1
WIRE,BATTERY (Ref # 47)	26011-511	1

1977 JS440

PARTS LIST

ELECTRIC CASE ('77-'78 A1/A1A/A2)

ITEM NAME	PART NUMBER	QUANTITY
WIRE,LEAD,BATTERY (Ref # 47)	26011-3002	1
CAP,STARTER (Ref # 48)	59176-506	1
GROMMET (Ref # 49)	92071-527	2
JOINT (Ref # 50)	59071-517	1
CONNECTOR,CORD (Ref # 51)	59221-505	1
WIRE,LEAD (Ref # 52)	26011-513	1
WIRE,LEAD (Ref # 53)	26011-514	1
WIRE,LEAD (Ref # 54)	26011-515	1
WIRE,LEAD (Ref # 55)	26011-512	2
CASE,FUEL TAP (Ref # 56)	32099-3752	1
WIRE,BATTERY EARTH (Ref # 57)	26011-501	1
FB BAT 12N16-3B (Ref # 58)	26012-1013	1
FB BAT 12N16-3B (Ref # 58)	26012-1013	1
CAP-BATTERY TERMINAL (Ref # 59)	59176-501	1
PLATE-BATTERY (Ref # 60)	59086-520	1
CUSHION,BATTERY (Ref # 61)	92075-509	1
PANEL-CONTROL (Ref # 62)	59226-3702	1
SCREW,8X22 (Ref # 63)	213R0822	4
SCREW,OVL CNTSNK,8X22 (Ref # 63)	222R0822	4
WASHER (Ref # 64)	92095-511	4
CABLE,CHOKE (Ref # 65)	59401-3001	1
CABLE,CHOKE (Ref # 65)	59401-3001	1
CABLE,CHOKE (Ref # 65-1)	59401-3001	1
GASKET (Ref # 66)	92065-538	1
WIRE,BATTERY (Ref # 67)	26011-511	1
WIRE,LEAD,STARTER (Ref # 67)	26011-519	1
CAP (Ref # 68)	11012-3012	2
WIRE,LEAD,STOP SW GRO (Ref # 69)	26011-517	1
HARNESS,SWITCH (Ref # 70)	26001-3005	1