


1982 KDX250

PARTS DIAGRAM

SWING ARM

Kawasaki

Let the Good Times Roll®





R
N

111
121
121
121
331

331
331
421
551
921

921
921
921
921
921



1982 KDX250

PARTS LIST SWING ARM

ITEM NAME	PART NUMBER	QUANTITY
CAP,SWING ARM (Ref # 11012)	11012-1207	4
GUIDE-CHAIN (Ref # 12053)	12053-1062	1
GUIDE-CHAIN (Ref # 12053A)	12053-1063	1
GUIDE-CHAIN (Ref # 12053B)	12053-1064	1
ARM-COMP-SWING (Ref # 33001)	33001-1129	1
SHAFT-SWING ARM (Ref # 33032)	33032-1042	1
ADJUSTER-CHAIN,LH (Ref # 33040)	33040-1060	2
SLEEVE,SWING ARM (Ref # 42036)	42036-1056	2
GUARD,CHAIN (Ref # 55020)	55020-1060	1
SCREW,6X10 (Ref # 92001)	92009-1286	2
NUT,14MM (Ref # 92015)	92015-1407	1
NUT-6MM (Ref # 92015A)	92015-1078	4
SHIM,SWING ARM (Ref # 92025)	92025-1116	4
PIN (Ref # 92043)	92043-1110	2
BRG,NEEDLE,HMK2030 (Ref # 92046)	92046-1031	2
BOLT,FLANGED,6X20 (Ref # 130)	130G0620	1
BOLT,FLANGED,6X45 (Ref # 130A)	130G0645	2
BOLT,FLANGED,6X55 (Ref # 130B)	130G0655	1
BOLT-FLANGED,6X60 (Ref # 130C)	130G0660	1
PIN COTTER 2.0X15 (Ref # 550)	550D2015	2