


1982 KDX250

PARTS DIAGRAM

SWING ARM

Kawasaki

Let the Good Times Roll®



R
N

111
121
121
121
331

331
331
421
551
921

921
921
921
921
921

921
921
921
921
921

921
921
921
921
921

921
921
921
921
921

921
921
921
921
921

921
921
921
921
921

1982 KDX250

PARTS LIST SWING ARM

ITEM NAME	PART NUMBER	QUANTITY
CAP,SWING ARM (Ref # 11012)	11012-1207	4
GUIDE-CHAIN (Ref # 12053)	12053-1062	1
GUIDE-CHAIN (Ref # 12053A)	12053-1063	1
GUIDE-CHAIN (Ref # 12053B)	12053-1064	1
ARM-COMP-SWING (Ref # 33001)	33001-1129	1
SHAFT-SWING ARM (Ref # 33032)	33032-1042	1
ADJUSTER-CHAIN,LH (Ref # 33040)	33040-1060	2
SLEEVE,SWING ARM (Ref # 42036)	42036-1056	2
GUARD,CHAIN (Ref # 55020)	55020-1060	1
SCREW,6X10 (Ref # 92001)	92009-1286	2
NUT,14MM (Ref # 92015)	92015-1407	1
NUT-6MM (Ref # 92015A)	92015-1078	4
SHIM,SWING ARM (Ref # 92025)	92025-1116	4
PIN (Ref # 92043)	92043-1110	2
BRG,NEEDLE,HMK2030 (Ref # 92046)	92046-1031	2
BOLT,FLANGED,6X20 (Ref # 130)	130G0620	1
BOLT,FLANGED,6X45 (Ref # 130A)	130G0645	2
BOLT,FLANGED,6X55 (Ref # 130B)	130G0655	1
BOLT-FLANGED,6X60 (Ref # 130C)	130G0660	1
PIN COTTER 2.0X15 (Ref # 550)	550D2015	2