


# 1981 KX80

## PARTS DIAGRAM

### HANDLEBAR ('81 KX80-C1)

**Kawasaki**

Let the Good Times Roll®



# 1981 KX80

## PARTS LIST

### HANDLEBAR ('81 KX80-C1)

| ITEM NAME                        | PART NUMBER  | QUANTITY |
|----------------------------------|--------------|----------|
| HANDLEBAR,F.BLACK (Ref # 1)      | 46003-1082   | 1        |
| BOLT,FLANGED,8X35 (Ref # 2)      | 130G0835     | 4        |
| HOLDER-HANDLEBAR (Ref # 3)       | 46012-008    | 2        |
| GRIP-ASSY (Ref # 4)              | 46019-1012   | 1        |
| SCREW PAN HEAD 5X20 (Ref # 5)    | 220B0520     | 2        |
| HOUSING CONTROL,R.H. (Ref # 6)   | 32099-1011   | 1        |
| CASE,R.H,GRIP,UPPER (Ref # 7)    | 32099-1014   | 1        |
| LEVER ASSY,FRONT BRK (Ref # 8)   | 46076-1010   | 1        |
| BOLT HEX HEAD 6X25 (Ref # 9)     | 110N0625     | 2        |
| WASHER PLAIN 6MM (Ref # 10)      | 410B0600     | 2        |
| SCREW CABLE ADJUST (Ref # 11)    | 46055-003    | 2        |
| NUT-LOCK (Ref # 12)              | 46056-005    | 2        |
| LEVER,FRONT BRAKE (Ref # 13)     | 46092-1014   | 1        |
| HOLDER,FR LEVER,F.BLK (Ref # 14) | 46060-011-21 | 1        |
| BOLT,HEX HEAD,5X22 (Ref # 15)    | 92007-046    | 2        |
| NUT-LOCK,5MM (Ref # 16)          | 92019-014    | 2        |
| SWITCH,ASSY,ENG STOP (Ref # 17)  | 27010-1018   | 1        |
| GRIP (Ref # 18)                  | 46075-1015   | 1        |
| LEVER ASSY,CLUTCH (Ref # 19)     | 46076-1011   | 1        |
| LEVER,CLUTCH (Ref # 20)          | 46092-1015   | 1        |
| HOLDER,CL LEVER,F.BLK (Ref # 21) | 46094-015-21 | 1        |
| BOOTS,LEVER HOLDER (Ref # 22)    | 49006-1017   | 2        |