

Jet Pump

Let the Good Times Roll®

Exploded view diagram of a vehicle headlight assembly. The diagram shows the main housing, lens, and various mounting and adjustment components. Key parts are labeled with numbers:

- 59366**: Main headlight housing.
- 92093**: Lens or cover plate.
- 59255**: Mounting bracket or arm.
- 92033**, **92049**, **92028**, **92049A**, **92055**: Various washers, spacers, and small components.
- 92150C**, **11051**: Mounting hardware and bracket.
- 410**, **92150A**: Bolts and nuts.
- 39145**: Lens or cover plate.
- 59496**: Headlight housing component.
- 92045A**, **13107**: Mounting hardware.
- 59136**: Headlight housing component.
- 92151**, **92150B**, **92022**, **92152**: Mounting hardware.
- 92028A**: Mounting hardware.
- 59476**: Headlight housing component.
- 92150**, **92161**, **92022A**, **59266**: Mounting hardware.
- 92151A**: Mounting hardware.
- 92027**, **92160**, **92022A**, **120**: Mounting hardware.
- 92002A**, **92055A**, **11012**, **92055B**, **11012A**: Mounting hardware.
- 92002**, **39112**: Mounting hardware.
- 59477**: Headlight housing component.
- 92028A**: Mounting hardware.

A "FRONT" arrow indicates the orientation of the assembly.

2000 1100 STX D.I.

PARTS LIST

Jet Pump



ITEM NAME	PART NUMBER	QUANTITY
-----------	-------------	----------