


# 1968 Bushwhacker

## PARTS DIAGRAM

### CYLINDER HEAD/CYLINDER



# 1968 Bushwhacker

## PARTS LIST

### CYLINDER HEAD/CYLINDER

ITEM NAME	PART NUMBER	QUANTITY
GASKET CYLINDER HEAD (Ref # 1)	11004-021	
WASHER SPRING 6MM (Ref # 2)	461F0600	
NUT,8MM (Ref # 3)	311B0800	
WASHER SPRING 8MM (Ref # 4)	461F0800	
WASHER SPRING 8MM (Ref # 4)	461F0800	
WASHER SPRING 8MM (Ref # 4)	461F0800	
CYLINDER HEAD (Ref # 5)	11001-031	
BOLT-UPSET,6X40 (Ref # 6)	112G0640	
STUD 8X40 (Ref # 7)	92004-003	
INSERT EXH PIPE HOLD (Ref # 8)	18070-001	
HOLDER EXHAUST PIPE (Ref # 9)	18069-017	
GASKET EXHAUST PIPE (Ref # 10)	18067-008	
CYLINDER (Ref # 11)	11005-041	
GASKET CYLINDER BASE (Ref # 12)	11009-012	