


# 1982 KX250

## PARTS DIAGRAM

### KICKSTARTER MECHANISM

E1340-0028



# 1982 KX250

## PARTS LIST

### KICKSTARTER MECHANISM

ITEM NAME	PART NUMBER	QUANTITY
BOSS,KICK PEDAL (Ref # 13061)	13061-1052	1
LEVER,KICK (Ref # 13064)	13064-1033	1
SHAFT,KICKSTARTER (Ref # 13066)	13066-1014	1
GUID,KICKSTARTER SPRG (Ref # 13070)	13070-011	1
RATCHET,KL250-D2 (Ref # 13078)	13078-1052	1
GUIDE-KICK (Ref # 13206)	13206-1059	1
STOPPER,KICKSTARTER (Ref # 32085)	32085-1016	1
IDLE GEAR, KICKSTRTER (Ref # 59051)	59051-1022	1
GEAR,KICKSTARTER,27T (Ref # 59051A)	59051-1023	1
BOLT,HEX HEAD,8X28 (Ref # 92001)	92001-1042	1
WASHER,PLAIN (Ref # 92022)	92022-1019	1
WASHER (Ref # 92022A)	92022-252	2
WASHER,PLAIN (Ref # 92022B)	92022-269	1
WASHER,PLAIN (Ref # 92022C)	92022-315	2
SPACER,17.2X23X0.5 (Ref # 92026)	92026-1037	1
CIRCLIP,18MM (Ref # 92033)	92033-029	1
"O" RING,11.5MM (Ref # 92055)	92055-072	2
SPRING KICK PEDAL (Ref # 92081)	92081-020	1
SPRING,RATCHET (Ref # 92081A)	92081-122	1
SPRING,KICKSTARTER (Ref # 92081B)	92081-1253	1
BOLT-UPSET (Ref # 110)	112G0618	2
SCREW, 8X16 (Ref # 290)	290Q0816	1
CIRCLIP 16MM (Ref # 480)	480J1600	2
CIR CLIP (Ref # 482)	482K0100	1
BALL STEEL 1/4' (Ref # 600)	600A0800	1