


# 1982 KX250

## PARTS DIAGRAM

### IGNITION

E1810-0048



# 1982 KX250

## PARTS LIST

### IGNITION

**Kawasaki**

Let the Good Times Roll®

ITEM NAME	PART NUMBER	QUANTITY
STATOR (Ref # 21003)	21003-1060	1
ROTOR (Ref # 21007)	21007-1049	1
IGNITER (Ref # 21119)	21119-1044	1
WASHER,PLAIN,8MM (Ref # 92022)	92022-276	1
WOODRUFF KEY (Ref # 92038)	92038-001	1
BOLT-HEX HEAD 8X30 (Ref # 114)	114G0830	1
BOLT-FLANGED,6X16 (Ref # 130)	130G0616	1
SCREW PAN HEAD 6X16 (Ref # 220)	220B0616	2
WASHER PLAIN 6MM (Ref # 411)	411B0600	2