


# 1983 GPz

## PARTS DIAGRAM

### FRONT FORK



# 1983 GPz

## PARTS LIST FRONT FORK

ITEM NAME	PART NUMBER	QUANTITY
GASKET,DRAIN PLUG (Ref # 11009)	44045-047	2
GASKET,FORK CYL BOLT (Ref # 11009A)	44045-051	2
PLATE,FORK COVER LWR (Ref # 13169)	13169-1840	2
PLATE,FORK COVER,UPP (Ref # 13169A)	13169-1841	2
VALVE,AIR (Ref # 16126)	16126-1043	1
FORK FRONT (Ref # 44001A)	44001-1431	1
PIPE-LEFT FORK OUTER (Ref # 44005A)	44005-1120	1
PIPE RIGHT FORK OUTER (Ref # 44006A)	44006-1120	1
PIPE-FORK INNER (Ref # 44013)	44013-1087	2
CYLINDER-FORK (Ref # 44022)	44022-1077	2
SPRING-FRONT FORK,L=5 (Ref # 44026)	44026-1138	2
SEAT,FORK SPRING (Ref # 44029)	44029-1012	2
COVER-FORK,LH (Ref # 44033)	44033-1091	1
COVER-FORK,RH (Ref # 44033A)	44033-1092	1
HOLDER-FORK UNDER,WG (Ref # 44037)	44037-1086	1
HOLDER-FORK UPPER (Ref # 44039)	44039-1055	1
BUSHING-FRONT FORK (Ref # 44065A)	44065-1020	2
TUBE-ASSY (Ref # 51044)	51044-1017	1
BOLT,FORK CYLINDER (Ref # 92001)	44041-078	2
BOLT (Ref # 92001B)	92001-1571	1
BOLT (Ref # 92001C)	92001-1745	6
NUT (Ref # 92015)	92015-1198	1
WASHER,FORK COVER (Ref # 92022)	92022-1111	2
SPACER (Ref # 92026)	92026-1108	2
CIRCLIP,FORK TOP (Ref # 92033)	92033-1023	2
RING,SNAP (Ref # 92033A)	92033-1055	2
SEAL-OIL (Ref # 92049)	92049-1089	2
"O" RING,SPRING SEAT (Ref # 92055)	92055-1060	2
RING-O (Ref # 92055A)	92055-1129	4

# 1983 GPz

## PARTS LIST

### FRONT FORK

ITEM NAME	PART NUMBER	QUANTITY
DAMPER RUBBER,FORK (Ref # 92075)	92075-1137	2
SEAL (Ref # 92093)	92093-1075	2
BOLT HEX HEAD 6X8 (Ref # 110)	110B0608	2
WASHER-SPRING,8MM,BLA (Ref # 461)	461K0800	6