


2010 Vulcan® 1700 Voyager® ABS

PARTS DIAGRAM

Other(Audio)



2010 Vulcan® 1700 Voyager® ABS

Kawasaki
Let the Good Times Roll®

PARTS LIST

Other(Audio)

| ITEM NAME | PART NUMBER | QUANTITY |
|-------------------------------------|-------------|----------|
| BOLT-FLANGED,6X22 (Ref # 130) | 130BA0622 | 3 |
| SCREW-PAN-CROSS,5X20 (Ref # 220) | 220AB0520 | 8 |
| BRACKET,ANTENNA STAY (Ref # 11055) | 11055-0683 | 1 |
| BRACKET,AUDIO (Ref # 11055A) | 11055-1510 | 1 |
| CAP,ANTENNA (Ref # 11065) | 11065-0305 | 1 |
| SWITCH-COMP (Ref # 13151) | 13151-0040 | 1 |
| PLATE,ANTENNA (Ref # 13272) | 13272-0674 | 1 |
| HOLDER,ANTENNA (Ref # 13280) | 13280-0285 | 1 |
| COVER,SPEAKER,LH (Ref # 14091) | 14091-0953 | 1 |
| COVER,SPEAKER,RH (Ref # 14091A) | 14091-0954 | 1 |
| COVER,ANTENNA STAY (Ref # 14091B) | 14091-1576 | 1 |
| COVER,SPEAKER BOX,LH (Ref # 14091C) | 14091-1773 | 1 |
| COVER,SPEAKER BOX,RH (Ref # 14091D) | 14091-1774 | 1 |
| RADIO-TUNER (Ref # 21179A) | 21179-0002 | 1 |
| ANTENNA (Ref # 21183) | 21183-0006 | 1 |
| SPEAKER (Ref # 21185) | 21185-0001 | 2 |
| HARNESS,ANTENNA (Ref # 26031) | 26031-0735 | 1 |
| SWITCH,SUB LAMP (Ref # 27010) | 27010-0107 | 1 |
| STAY,ANTENNA (Ref # 35063) | 35063-0519 | 1 |
| NUT,FLANGED,5MM (Ref # 92015) | 92015-1259 | 1 |
| NUT (Ref # 92015A) | 92015-1700 | 4 |
| NUT,WELL,5MM (Ref # 92015B) | 92015-1757 | 8 |
| COLLAR,L=13.1,BLACK (Ref # 92027) | 92027-1450 | 3 |
| DAMPER (Ref # 92075) | 92075-1690 | 3 |
| BOLT,SOCKET,6X30 (Ref # 92154) | 92154-0206 | 4 |
| SCREW,5X16 (Ref # 92172) | 92172-0322 | 4 |
| SCREW,5X18 (Ref # 92172A) | 92172-0428 | 4 |
| NUT,WELL,5MM (Ref # 92210) | 92210-0532 | 4 |