

2010 Bayou[®] 250


PARTS DIAGRAM

Ignition Switch

Kawasaki

Let the Good Times Roll[®]

F2770



2010 Bayou[®] 250

PARTS LIST

Ignition Switch

ITEM NAME	PART NUMBER	QUANTITY
LEVER, REVERSE LOCK (Ref # 13168)	13168-1760	1
COVER, KEY (Ref # 14024)	14024-1551	4
LAMP-ASSY, NEUTRAL & REVERSE (Ref # 23016)	23016-1083	1
SWITCH-ASSY-IGNITION (Ref # 27005)	27005-0002	1
KEY-LOCK, BLANK (Ref # 27008)	27008-1041	1
KEY-LOCK, BLANK (Ref # 27008A)	27008-1042	1
KEY-LOCK, BLANK (Ref # 27008B)	27008-1043	1
KEY-LOCK, BLANK (Ref # 27008C)	27008-1044	1
KEY-LOCK, BLANK, W/COVER (Ref # 27008D)	27008-1132	1
KEY-LOCK, BLANK, W/COVER (Ref # 27008E)	27008-1133	1
KEY-LOCK, BLANK, W/COVER (Ref # 27008F)	27008-1134	1
KEY-LOCK, BLANK, W/COVER (Ref # 27008G)	27008-1135	1
SWITCH, REAR BRAKE (Ref # 27010)	27010-0008	1
BRACKET-SWITCH, REAR BRAKE (Ref # 32059)	32059-1106	1
SCREW, TAPPING, 4X12 (Ref # 92009)	92009-1533	1
WASHER, PLAIN, 4MM (Ref # 92022)	92022-1947	1
BULB, 12V 3W, T7 (Ref # 92069)	92069-1020	2
BAND, L=149 (Ref # 92072)	92072-031	1
BAND, L=188 (Ref # 92072A)	92072-1239	2
SPRING, REAR BRAKE SWITCH (Ref # 92145)	92145-0061	1
NUT, IGNITION SWITCH (Ref # 92210)	92210-1109	1