


2003 Lakota Sport

PARTS DIAGRAM

Ignition Switch

Kawasaki

Let the Good Times Roll®



2003 Lakota Sport

PARTS LIST

Ignition Switch

ITEM NAME	PART NUMBER	QUANTITY
COVER,KEY (Ref # 14024)	14024-1551	4
HARNESS (Ref # 26030)	26030-1058	1
SWITCH-ASSY-IGNITION (Ref # 27005)	27005-1186	1
KEY-LOCK,BLANK (Ref # 27008)	27008-1041	1
KEY-LOCK,BLANK (Ref # 27008A)	27008-1042	1
KEY-LOCK,BLANK (Ref # 27008B)	27008-1043	1
KEY-LOCK,BLANK (Ref # 27008C)	27008-1044	1
KEY-LOCK,BLANK (Ref # 27008D)	27008-1132	1
KEY-LOCK,BLANK (Ref # 27008E)	27008-1133	1
KEY-LOCK,BLANK (Ref # 27008F)	27008-1134	1
KEY-LOCK,BLANK (Ref # 27008G)	27008-1135	1
SWITCH,BRAKE (Ref # 27010A)	27010-1294	1
SWITCH,REAR BRKAE (Ref # 27010B)	27010-1473	1
SPRING,BRAKE LAMP SWITCH (Ref # 27011)	27011-021	1
BOOT (Ref # 49006)	49006-1261	1
BAND,L=188 (Ref # 92072)	92072-1239	4
NUT,IGNITION SWITCH (Ref # 92210)	92210-1109	1