

Crankcase

Let the Good Times Roll®

Exploded view diagram of a motorcycle engine assembly. The diagram shows the main engine block (14001) and various components, including the cylinder head (14067), pistons (92045A, 92045B, 92045C, 92045D, 92045E, 92045F, 92045G), connecting rods (92190), and other parts. The diagram is labeled with part numbers and includes a 'FRONT' arrow indicating the orientation.

Part numbers shown in the diagram:

- 14001
- 14067
- 92042
- 92045E
- 92045F
- 92045A
- 92045D
- 92045E
- 92045G
- 92045B
- 92001
- 92045C
- 92045
- 92143
- 92049
- 92022
- 92150
- 92065
- 92066
- 92170
- 172
- 92190
- 132A
- 132
- 92150B
- 92150A



2004 Super Sherpa (Canada Only)

PARTS LIST

Crankcase

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED-SMALL (Ref # 132)	132Y0650	6
BOLT-FLANGED-SMALL (Ref # 132A)	132Y0670	2
BOLT-STUD,6X80 (Ref # 172)	172G0680	1
SET-CRANKCASE (Ref # 14001)	14001-5359	1
FITTING,BREATHER (Ref # 14067)	14067-006	1
BOLT,W/WASHER,6X14 (Ref # 92001)	92001-1829	2
WASHER,10.2X18X1.0,SK5 (Ref # 92022)	92022-1415	1
PIN,DOWEL,6.3X8X14 (Ref # 92042)	92042-007	2
BEARING-BALL,#6905 (Ref # 92045)	92045-036	1
BEARING-BALL,TMB204 JR (Ref # 92045A)	92045-1041	1
BEARING-BALL,TMB203LU (Ref # 92045B)	92045-1287	1
BEARING-BALL,TMB205LU (Ref # 92045C)	92045-1288	1
BEARING-BALL,TMB203 (Ref # 92045D)	92045-1291	1
BEARING-BALL,TMB302JR2 (Ref # 92045E)	92045-1346	2
BEARING-BALL,TMB306JR2 (Ref # 92045F)	92045-1347	1
BEARING-BALL,3TM-6207CJR2 (Ref # 92045G)	92045-1348	1
SEAL-OIL,TC32457 (Ref # 92049)	92049-1577	1
GASKET,10.5X16X1 (Ref # 92065)	92065-058	1
PLUG,DRAIN (Ref # 92066)	92066-1241	1
COLLAR (Ref # 92143)	92143-1263	1
BOLT,RETURN SPRING (Ref # 92150)	92150-1803	1
BOLT,SOCKET,6X50 (Ref # 92150A)	92150-1874	1
BOLT,SOCKET,6X35 (Ref # 92150B)	92150-1875	1
CLAMP,TUBE (Ref # 92170)	92170-1803	1
TUBE (Ref # 92190)	92190-1493	1