


# 2001 Bayou 300

## PARTS DIAGRAM

### Ignition Switch

**Kawasaki**

Let the Good Times Roll®



# 2001 Bayou 300

## PARTS LIST

### Ignition Switch

| ITEM NAME                               | PART NUMBER | QUANTITY |
|-----------------------------------------|-------------|----------|
| COVER,KEY (Ref # 14024)                 | 14024-1551  | 4        |
| LAMP-ASSY,NEUTRAL&REVERSE (Ref # 23016) | 23016-1083  | 1        |
| HARNESS (Ref # 26030)                   | 26030-1058  | 1        |
| HARNESS,REAR BRAKE (Ref # 26030A)       | 26030-1062  | 1        |
| SWITCH-ASSY-IGNITION (Ref # 27005)      | 27005-1201  | 1        |
| KEY-LOCK,BLANK (Ref # 27008)            | 27008-1041  | 1        |
| KEY-LOCK,BLANK (Ref # 27008A)           | 27008-1042  | 1        |
| KEY-LOCK,BLANK (Ref # 27008B)           | 27008-1043  | 1        |
| KEY-LOCK,BLANK (Ref # 27008C)           | 27008-1044  | 1        |
| KEY-LOCK,BLANK (Ref # 27008D)           | 27008-1132  | 1        |
| KEY-LOCK,BLANK (Ref # 27008E)           | 27008-1133  | 1        |
| KEY-LOCK,BLANK (Ref # 27008F)           | 27008-1134  | 1        |
| KEY-LOCK,BLANK (Ref # 27008G)           | 27008-1135  | 1        |
| SWITCH,BRAKE LAMP (Ref # 27010)         | 27010-025   | 1        |
| SPRING,SWITCH (Ref # 27011)             | 27011-014   | 1        |
| BRACKET-SWITCH,REAR BRAKE (Ref # 32059) | 32059-1107  | 1        |
| BULB,12V 3W,T7 (Ref # 92069)            | 92069-1020  | 2        |
| BAND,L=123 (Ref # 92072)                | 92072-030   | 2        |
| BAND,L=188 (Ref # 92072A)               | 92072-1239  | 5        |
| NUT,IGNITION SWITCH (Ref # 92210)       | 92210-1109  | 1        |