


2007 KLX250S

PARTS DIAGRAM

Chassis Electrical Equipment

Kawasaki

Let the Good Times Roll®



2007 KLX250S

PARTS LIST

Chassis Electrical Equipment

ITEM NAME	PART NUMBER	QUANTITY
CAP,BUNGEE CORD HOOK (Ref # 11012)	11012-1589	1
FUSE-ASSY (Ref # 26004)	26004-1089	1
FUSE,10A,L=30 (Ref # 26006)	26006-1002	3
WIRE-LEAD,BATTERY(-) (Ref # 26011)	26011-1592	1
WIRE-LEAD,BATTERY(+) (Ref # 26011A)	26011-1609	1
BATTERY,FTX7L-BS,12V6AH (Ref # 26012)	26012-0068	1
HARNESS,MAIN (Ref # 26031)	26031-0372	1
RELAY-ASSY (Ref # 27002)	27002-1086	1
RELAY-ASSY,TURN SIGNAL (Ref # 27002A)	27002-1101	1
HORN (Ref # 27003)	27003-0029	1
DIODE (Ref # 49018)	49018-1052	1
CLAMP,SPEED,L=58 (Ref # 92037)	92037-1163	5
BAND,L=250 (Ref # 92072)	92072-1237	2
BAND,L=215 (Ref # 92072A)	92072-1288	1
BAND,L=140 (Ref # 92072B)	92072-1293	4
BOLT,FLANGED,6X14 (Ref # 92150)	92150-1689	1
CLAMP,L=150 (Ref # 92170)	92170-1114	1
CLAMP (Ref # 92171)	92171-1437	1
CLAMP (Ref # 92171A)	92171-1438	1