

2003 KLX400SR


PARTS DIAGRAM

Cam Chain/Tensioner

Kawasaki

Let the Good Times Roll®

E1212



2003 KLX400SR

PARTS LIST

Cam Chain/Tensioner

ITEM NAME	PART NUMBER	QUANTITY
GASKET,TENSIONER ADJUSTER (Ref # 11061)	11061-S073	1
GASKET (Ref # 11061A)	11061-S074	1
TENSIONER-ASSY (Ref # 12048)	12048-S006	1
GUIDE-CHAIN,FR (Ref # 12053)	12053-S014	1
GUIDE-CHAIN,CNT (Ref # 12053A)	12053-S015	1
GUIDE-CHAIN,RR (Ref # 12053B)	12053-S023	1
RETAINER (Ref # 14020)	14020-S006	1
CHAIN,CAMSHAFT DRIVE (Ref # 92057)	92057-S012	1
PLUG (Ref # 92066)	92066-S034	1
SPRING,STARTER IDLE GEAR (Ref # 92145)	92145-S155	1
BOLT,TENSIONER ADJUSTER (Ref # 92153)	92153-S257	2
BOLT,CAM CHAIN TENSIONER (Ref # 92153A)	92153-S291	1
SCREW (Ref # 92172)	92172-S112	1
WASHER,CAM CHAIN (Ref # 92200)	92200-S128	1