

Transmission

Let the Good Times Roll®

Exploded view diagram of a mechanical assembly, showing various components and their assembly sequence. The diagram includes a central shaft assembly and several gear and bearing components. The components are labeled with part numbers:

- 14020A
- 92172
- 92026
- 92045A
- 92139
- 13262D
- 92180
- 13262H
- 92200
- 13262F
- 13262G
- 92180A
- 92033
- 92200A
- 13128
- 92139A
- 13262E
- 92045C
- 92049
- 92055
- 14020B
- 92172B
- 13144
- 92026A
- 92058
- 92057
- 92033
- 13262
- 92045B
- 92033A
- 13262B
- 13262A
- 92033
- 13262C
- 92045
- 13127
- 92172A
- 14020
- 92200B
- 92210

A "FRONT" arrow is located at the bottom left of the diagram.

© 2026 Kawasaki Motors Corp., U.S.A.

2003 KLX400SR

PARTS LIST

Transmission



ITEM NAME	PART NUMBER	QUANTITY
-----------	-------------	----------