

## Transmission

**Let the Good Times Roll®**

Exploded view diagram of a mechanical assembly, showing various components and their assembly sequence. The diagram includes a central shaft assembly and several gear and bearing components. The parts are labeled with their respective part numbers:

- 14020A
- 92172
- 92026
- 92045A
- 92139
- 13262D
- 92180
- 13262H
- 92200
- 13262F
- 13262G
- 92180A
- 92033
- 92200A
- 13128
- 13262E
- 92139A
- 92055
- 14020B
- 92172B
- 13144
- 92045C
- 92049
- 92026A
- 14020
- 92172A
- 92045
- 13127
- 92058
- 92033
- 92057
- 92033
- 13262C
- 13262A
- 13262B
- 13262
- 92045B
- 92200B
- 92210

A "FRONT" arrow is located at the bottom left of the diagram.

# 2003 KLX400R

## PARTS LIST

### Transmission



| ITEM NAME | PART NUMBER | QUANTITY |
|-----------|-------------|----------|
|-----------|-------------|----------|